

SCNC (consumer series) URL COMMAND LIST

File Status: <input checked="" type="checkbox"/> Draft <input type="checkbox"/> Official	Author / Date:	Sharx Security / 2014-08-02
	Checker / Date:	Not 100% checked yet
	Confirm / Date:	Not confirmed yet
	Current Version:	V5.72
	Current Date:	2014-08-02
	No:	
	Known Issues:	
	Firmware Version	V5.7x

Contents

Get RTSP H.264 Stream	5
Get RTSP MPEG4 Stream	6
Get RTSP MJPEG Stream	7
Get RTSP Audio Stream	8
Get HTTP MJPEG Stream.....	9
Get HTTP Snapshot Image	10
Get HTTP Alarm Stream	11
Get Video Parameters.....	12
Set Video Parameters	13
Get Microphone Parameters	14
Set Microphone Parameters	15
Get Speaker Parameters	16
Set Speaker Parameters.....	17
Get Privacy Mode	18
Set Privacy Mode.....	19
Get LED Parameters	20
Set LED Parameters	21
Get Stream Parameters	22
Set Stream Parameters.....	25
Get OSD Parameters	28
Set OSD Parameters.....	29
Get Night Vision Parameters.....	30
Set Night Vision Parameters	31
Get WiFi Parameters.....	32
Set WiFi Parameters	34
Get WiFi Status	36
Wifi Test.....	38
Get Wifi Test Status	39
Wifi Scan	40
Get Wifi List	41
Get Ethernet Status	42
Get TCP/IP Parameters	43
Set TCP/IP Parameters	44
Get TCP/IP Status.....	45
Get HTTP Port.....	46
Set HTTP Port	47
Get RTP Port Range	48
Set RTP Port Range.....	49
Get DDNS Parameters	50
Set DDNS Parameters.....	51
Get DDNS Status	52

Get UPnP Parameters	53
Set UPnP Parameters.....	54
Get UPnP Status.....	55
Get RTHP Parameters (still unsupported)	56
Set RTHP Parameters (still unsupported).....	57
Get Storage Parameters	58
Set Storage Parameters	60
Get Storage Status	62
Get Storage File List.....	63
SD Card Format.....	64
Get SD Card Format Status	65
Get Digital I/O Parameters	66
Set Digital I/O Parameters.....	67
Get Motion Detection Parameters.....	68
Set Motion Detection Parameters	69
Get Schedule Parameters	70
Set Schedule Parameters.....	72
Get EMail Alarm Sending Parameters.....	74
Set EMail Alarm Sending Parameters	76
Get EMail Periodic Sending Parameters.....	78
Set EMail Periodic Sending Parameters	80
Get FTP Alarm Sending Parameters	82
Set FTP Alarm Sending Parameters.....	84
Get FTP Periodic Sending Parameters	86
Set FTP Periodic Sending Parameters.....	88
Get HTTP Alarm Sending Parameters	90
Set HTTP Alarm Sending Parameters.....	91
Get HTTP Periodic Sending Parameters	92
Set HTTP Periodic Sending Parameters.....	94
Get Storage Alarm Snapshot Parameters.....	95
Set Storage Alarm Snapshot Parameters	96
Get Storage Periodic Snapshot Parameters.....	97
Set Storage Periodic Snapshot Parameters	99
Get Storage Alarm Recording Parameters	101
Set Storage Alarm Recording Parameters.....	103
Get Storage Continuous Recording Parameters.....	104
Set Storage Continuous Recording Parameters.....	105
Get Storage FTP Sending Parameters.....	106
Set Storage FTP Sending Parameters	107
Get Identity Parameters.....	108
Set Identity Parameters	109
Add User	110
Edit User.....	111
Delete User.....	112
Get User List.....	113
Get Active Users List.....	114

Get Allow Anonymous Access Parameters.....	115
Set Allow Anonymous Access Parameters	116
Get Authentication Method.....	117
Set Authentication Method	118
Get Date and Time.....	119
Set Date and Time	122
Get Date Format	125
Set Date Format.....	126
Get NTP Parameters.....	127
Set NTP Parameters	128
Get Auto Reboot Parameters.....	129
Set Auto Reboot Parameters	130
System Reboot.....	131
Get Model.....	132
Get Firmware Version	133
Get Hardware Address.....	134
Get System Information	135
Appendix URL Command Testing	136

Get RTSP H.264 Stream

Command Name	Get RTSP H.264 Stream
Command URL	rtsp://<Camera IP>:<HTTP port>/live/0/h264.sdp rtsp://<Camera IP>:<HTTP port>/live/1/h264.sdp rtsp://<Camera IP>:<HTTP port>/live/2/h264.sdp
Parameters	Null
Description	Get RTSP H.264 stream Can use RealPlayer to play the live stream. Can use QuickTime player to play the live stream. Can use VLC player to play the live stream.

Get RTSP MPEG4 Stream

Command Name	Get RTSP MPEG4 Stream
Command URL	rtsp://<Camera IP>:<HTTP port>/live/0/mpeg4.sdp rtsp://<Camera IP>:<HTTP port>/live/1/mpeg4.sdp rtsp://<Camera IP>:<HTTP port>/live/2/mpeg4.sdp
Parameters	Null
Description	Get RTSP MPEG4 stream Can use RealPlayer to play the live stream. Can use QuickTime player to play the live stream. Can use VLC player to play the live stream.
Response	

Get RTSP MJPEG Stream

Command Name	Get RTSP MJPEG Stream
Command URL	rtsp://<Camera IP>:<HTTP port>/live/0/mjpeg.sdp rtsp://<Camera IP>:<HTTP port>/live/1/mjpeg.sdp rtsp://<Camera IP>:<HTTP port>/live/2/mjpeg.sdp
Parameters	Null
Description	Get RTSP MJPEG stream Can use RealPlayer to play the live stream. Can use QuickTime player to play the live stream. Can use VLC player to play the live stream.
Response	

Get RTSP Audio Stream

Command Name	Get RTSP Audio Stream
Command URL	rtsp://<Camera IP>:<HTTP port>/live/0/audio.sdp rtsp://<Camera IP>:<HTTP port>/live/1/audio.sdp rtsp://<Camera IP>:<HTTP port>/live/2/audio.sdp
Parameters	Null
Description	Get RTSP audio stream Can use RealPlayer to play the live stream. Can use QuickTime player to play the live stream. Can use VLC player to play the live stream.
Response	

Get HTTP MJPEG Stream

Command Name	Get HTTP MJPEG Stream
Command URL	http://<Camera IP>:<HTTP port>/live/0/mjpeg.jpg http://<Camera IP>:<HTTP port>/live/1/mjpeg.jpg http://<Camera IP>:<HTTP port>/live/2/mjpeg.jpg
Parameters	Null
Description	Get HTTP motion JPEG stream Can use VLC player to play the live stream, Can use Firefox, Safari etc. browser to play the live stream.
Response	

Get HTTP Snapshot Image

Command Name	Get HTTP Snapshot Image
Command URL	http://<Camera IP>:<HTTP port>/live/0/jpeg.jpg http://<Camera IP>:<HTTP port>/live/1/jpeg.jpg http://<Camera IP>:<HTTP port>/live/2/jpeg.jpg
Parameters	Null
Description	Snapshot current image from Camera stream. This file is different every time.
Response	A file named jpeg.jpg

Get HTTP Alarm Stream

Command Name	Get HTTP Alarm Stream
Command URL	http://<Camera IP>:<HTTP port>/alarm.dat
Parameters	Null
Description	Get HTTP alarm event and motion detection stream
Response	

Get Video Parameters

Command Name	Get Video Parameters
Command URL	http://<Camera IP>/form/getVideo
Parameters	Null
Description	Get video parameters
Response	<p>000 Success 100 Failed</p> <p>LIGHTFREQ=<value> Frequency of light, valid value is: 50 - 50 Hz 60 - 60 Hz</p> <p>HFLIP=<value> Image mirror (horizontal flip), valid value is: 0 – Off 1 – On</p> <p>VFLIP=<value> Image vertical flip, valid value is: 0 – Off 1 – On</p> <p>SENSORSIZE =<value> Image sensor size, valid value is: NTSC – 720x480 PAL – 720x576 VGA – 640x480 HD720P – 1280x720 HD1080P – 1920x1080</p>

Set Video Parameters

Command Name	Set Video Parameters
Command URL	http://<Camera IP>/form/setVideo?<Param1>&<Param2>& ...
Parameters	LIGHTFREQ=<value> Frequency of light, valid value is: 50 - 50 Hz 60 - 60 Hz HFLIP=<value> Image mirror (horizontal flip), valid value is: 0 - Off 1 - On VFLIP=<value> Image vertical flip, valid value is: 0 - Off 1 - On
Description	Set video parameters
Response	000 Success 100 Failed

Get Microphone Parameters

Command Name	Get Microphone Parameters
Command URL	http://<Camera IP>/form/getMicrophone
Parameters	Null
Description	Get Microphone parameters
Response	000 Success 100 Failed ENABLE=<value> Open or close the microphone, valid value is: 0 – Disable 1 – Enable VOLUME=<value> Microphone volume, valid value is: 0~100

Set Microphone Parameters

Command Name	Set Microphone Parameters
Command URL	http://<Camera IP>/form/setMicrophone?<Param1>&<Param2>& ...
Parameters	ENABLE=<value> Open or close the microphone, valid value is: 0 – Disable 1 – Enable VOLUME=<value> Microphone volume, valid value is: 0~100
Description	Set microphone parameters
Response	000 Success 100 Failed

Get Speaker Parameters

Command Name	Get Speaker Parameters
Command URL	http://<Camera IP>/form/getSpeaker
Parameters	Null
Description	Get speaker parameters
Response	000 Success 100 Failed ENABLE=<value> Open or close the speaker, valid value is: 0 – Disable 1 – Enable VOLUME=<value> Speaker volume, valid value is: 0~100

Set Speaker Parameters

Command Name	Set Speaker Parameters
Command URL	http://<Camera IP>/form/setSpeaker?<Param1>&<Param2>& ...
Parameters	ENABLE=<value> Open or close the speaker, valid value is: 0 – Disable 1 – Enable VOLUME=<value> Speaker out volume, valid value is: 0~100
Description	Set speaker parameters
Response	000 Success 100 Failed

Get Privacy Mode

Command Name	Get Privacy Mode
Command URL	http://<Camera IP>/form/getPrivacy
Parameters	Null
Description	Get privacy mode
Response	000 Success 100 Failed ENABLE=<value> Enable or disable privacy mode, valid value is: 0 – Disable privacy mode 1 – Enable privacy mode

Set Privacy Mode

Command Name	Set Privacy Mode
Command URL	http://<Camera IP>/form/setPrivacy?<Param1>&<Param2>& ...
Parameters	ENABLE=<value> Enable or disable privacy mode, valid value is: 0 – Disable privacy mode 1 – Enable privacy mode
Description	Set privacy mode
Response	000 Success 100 Failed

Get LED Parameters

Command Name	Get LED Parameters
Command URL	http://<Camera IP>/form/getLed
Parameters	Null
Description	Get LED parameters
Response	000 Success 100 Failed ENABLE=<value> Turn on or turn off LED light, valid value is: 0 – Turn off LED light 1 – Turn on LED light

Set LED Parameters

Command Name	Set LED Parameters
Command URL	http://<Camera IP>/form/setLed?<Param1>&<Param2>& ...
Parameters	ENABLE=<value> Open or close LED light, valid value is: 0 – Turn off LED light 1 – Turn on LED light
Description	Set LED parameters
Response	000 Success 100 Failed

Get Stream Parameters

Command Name	Get Stream Parameters
Command URL	http://<Camera IP>/form/getStream
Parameters	<p>TYPE=<value> Stream type, valid value is:</p> <ul style="list-style-type: none"> 0 – Primary stream 1 – Secondary stream 2 – Mobile stream
Description	Get stream parameters
Response	<p>000 Success 100 Failed</p> <p>ENABLE=<value> Stream can be enabled or not, valid value is:</p> <ul style="list-style-type: none"> 0 - Disable 1 - Enable <p>SIZE=<value> Value is the size of video, valid value is: For SCNC3705 version:</p> <ul style="list-style-type: none"> FSIZE – Full size (640x480) HSIZE – Half size (480x360) QSIZE – Quarter size (320x240) QQSIZE –Quarter and quarter size (160x120) QCIF –QCIF size (176x144) <p>For SCNC3804, SCNC3805, SCNC2800 version:</p> <ul style="list-style-type: none"> HDSIZE – HD size (1280x720) FSIZE – Full size (768x432) QSIZE – Quarter size (512x288) QHSIZE – Quarter and half size (480x270) QQSIZE –Quarter and quarter size (256x144) QCIF –QCIF size (176x144) <p>For SCNC3904, SCNC3905, SCNC2900 version:</p> <ul style="list-style-type: none"> HHDSIZE – High HD size (1920x1080) HDSIZE – HD size (1280x720) FSIZE – Full size (768x432) QSIZE – Quarter size (512x288) QHSIZE – Quarter and half size (480x270) QQSIZE –Quarter and quarter size (256x144) QCIF –QCIF size (176x144) <p>FRAMERATE=<value></p>

Max frame rate, valid value is:
30 – 30 fps
25 – 25 fps
20 – 20 fps
15 – 15 fps
10 – 10 fps
8 – 8 fps
6 – 6 fps
5 – 5 fps
4 – 4 fps
3 – 3 fps
2 – 2 fps
1 – 1 fps

H264BITRATE=<value>
H264 bitrate of bandwidth, valid value is:
4096 - 4096 kbps
2048 - 2048 kbps
1536 - 1536 kbps
1024 - 1024 kbps
768 - 768 kbps
512 - 768 kbps
256 - 256 kbps
128 - 128 kbps
64 - 64 kbps

MPEG4BITRATE=<value>
MPEG4 bitrate of bandwidth, valid value is:
4096 - 4096 kbps
2048 - 2048 kbps
1536 - 1536 kbps
1024 - 1024 kbps
768 - 768 kbps
512 - 768 kbps
256 - 256 kbps
128 - 128 kbps
64 - 64 kbps

MJPEGQUALITY=<value>
MJPEG video quality, valid value is:
20 – 100

JPEGQUALITY=<value>
Snapshot image quality, valid value is:
20 – 100

AUDIOCODEC=<value>
Audio codec, valid value is:
NONE - Disable
AACLC - AAC-LC

AUDIOBITRATE=<value>

Audio bitrate, valid value is:

40000 - 40kbps

32000 - 32kbps

24000 - 24kbps

16000 - 16kbps

AUTH=<value>

Stream does or does not needs authentication, valid value is:

0 – Disable

1 – Enable

H264BUFFERSEC =<value>

Prerecord seconds, valid value is 0, 3, 5 and 10

Set Stream Parameters

Command Name	Set Stream Parameters
Command URL	http://<Camera IP>/form/setStream?<Param1>&<Param2>& ...
Parameters	<p>TYPE=<value> 0 – Primary stream 1 – Secondary stream 2 – Mobile stream</p> <p>ENABLE=<value> Stream can be visited or not, (The value must be 1), valid value is: 0 - Disable 1 - Enable</p> <p>SIZE=<value> Value is the size of Video, valid value is: For VGA version: FSIZE – Full size (640x480) HSIZE – Half size (480x360) QSIZE – Quarter size (320x240) QQSIZE – Quarter and quarter size (160x120) QCIF – QCIF size (176x144) For HD720P version: HDSIZE – HD size (1280x720) FSIZE – Full size (768x432) HSIZE – Half size (640x360) QSIZE – Quarter size (512x288) QHSIZE – Quarter and half size (480x270) QQSIZE – Quarter and quarter size (256x144) QCIF – QCIF size (176x144) For HD1080P version: HHDSIZE – High HD size (1920x1080) HDSIZE – HD size (1280x720) FSIZE – Full size (768x432) HSIZE – Half size (640x360) QSIZE – Quarter size (512x288) QHSIZE – Quarter and half size (480x270) QQSIZE – Quarter and quarter size (256x144) QCIF – QCIF size (176x144)</p> <p>FRAMERATE=<value> Max frame rate, valid value is:</p>

30 – 30 fps
25 – 25 fps
20 – 20 fps
15 – 15 fps
10 – 10 fps
8 – 8 fps
6 – 6 fps
5 – 5 fps
4 – 4 fps
3 – 3 fps
2 – 2 fps
1 – 1 fps

H264BITRATE=<value>

H264 bitrate of bandwidth, valid value is:

4096 - 4096 kbps
2048 - 2048 kbps
1536 - 1536 kbps
1024 - 1024 kbps
768 - 768 kbps
512 - 768 kbps
256 - 256 kbps
128 - 128 kbps
64 - 64 kbps

MPEG4BITRATE=<value>

MPEG4 bitrate of bandwidth, valid value is:

4096 - 4096 kbps
2048 - 2048 kbps
1536 - 1536 kbps
1024 - 1024 kbps
768 - 768 kbps
512 - 768 kbps
256 - 256 kbps
128 - 128 kbps
64 - 64 kbps

MJPEGQUALITY=<value>

MJPEG video quality, valid value is:

20 – 100

JPEGQUALITY=<value>

Snapshot image quality, valid value is:

20 – 100

AUDIOCODEC=<value>

Audio codec, valid value is:

NONE - Disable
AACLC - AAC-LC

AUDIOBITRATE=<value>

	Audio bitrate, valid value is: 40000 - 40kbps 32000 - 32kbps 24000 - 24kbps 16000 - 16kbps AUTH=<value> Stream does or does not needs authentication, valid value is: 0 - Disable 1 – Enable H264BUFFERSEC =<value> Prerecord seconds, valid value is 0, 3, 5 and 10
Description	Set stream parameters
Response	000 Success 100 Failed

Get OSD Parameters

Command Name	Get OSD Parameters
Command URL	http://<Camera IP>/form/getOsd
Parameters	Null
Description	Get OSD parameters
Response	<p>000 Success 100 Failed</p> <p>ENABLE=<value> Enable or disable OSD function, valid value is: 0 – Disable OSD 1 – Enable OSD</p> <p>ENABLETIME=<value> Display date and time or not, valid value is: 0 – Disable display date and time 1 – Enable display date and time</p> <p>ENABLESYSTEMNAME=<value> Display system name or not, valid value is: 0 – Disable display system name 1 – Enable display system name</p> <p>ENABLESTRING=<value> Display text or not, valid value is: 0 – Disable display text 1 – Enable display text</p> <p>STRING=<value> Display text, valid value is: 0-24 characters</p>

Set OSD Parameters

Command Name	Set OSD Parameters
Command URL	http://<Camera IP>/form/setOsd?<Param1>&<Param2>& ...
Parameters	<p>ENABLE=<value> Enable or Disable OSD function, valid value is: 0 – Disable OSD 1 – Enable OSD</p> <p>ENABLETIME=<value> Display date and time or not, valid value is: 0 – Disable display date and time 1 – Enable display date and time</p> <p>ENABLESYSTEMNAME=<value> Display system name or not, valid value is: 0 – Disable display system name 1 – Enable display system name</p> <p>ENABLESTRING=<value> Display appointed words or not, valid value is: 0 – Disable display text 1 – Enable display text</p> <p>STRING=<value> Display text, valid value is: 0-24 characters</p>
Description	Set OSD parameters
Response	<p>000 Success</p> <p>100 Failed</p>

Get Night Vision Parameters

Command Name	Get Night Vision Parameters
Command URL	http://<Camera IP>/form/getNightVision
Parameters	Null
Description	Get night vision parameters
Response	<p>000 Success 100 Failed</p> <p>IRLED=<value> Infrared LED control, valid value is: 0 – Off Turn off Infrared LED 1 – On Turn on Infrared LED 2 – Auto Control infrared LED automatically</p> <p>BWMODE=<value> Black and white mode control, valid value is: 0 – Off Never use black and white mode 1 – On Always use black and white mode 2 – Auto Control black and white mode automatically</p> <p>MOONLIGHT=<value> Moon light mode control, valid value is: 0 – Off Never use moon light mode 1 – On Always use moon light mode 2 – Auto Control moon light mode automatically</p> <p>IRCUT=<value> IR-cut control, valid value is: 0 – Off Always set to color filter 1 – On Always set to IR filter 2 – Auto Control IR-cut automatic</p>

Set Night Vision Parameters

Command Name	Set Night Vision Parameters
Command URL	http://<Camera IP>/form/setNightVision?<Param1>&<Param2>& ...
Parameters	<p>IRLED=<value> Infrared LED control, valid value is: 0 – Off Turn off Infrared LED 1 – On Turn on Infrared LED 2 – Auto Control infrared LED automatically</p> <p>BWMODE=<value> Black and White mode control, valid value is: 0 – Off Never use black and white mode 1 – On Always use black and white mode 2 – Auto Control black and white mode automatically</p> <p>MOONLIGHT=<value> Moon light mode control, valid value is: 0 – Off Never use moon light mode 1 – On Always use moon light mode 2 – Auto Control moon light mode automatically</p> <p>IRCUT=<value> IR-cut Control, valid value is: 0 – Off Always set to color filter 1 – On Always set to IR filter 2 – Auto Control IR-cut automatic</p>
Description	Set night vision parameters
Response	<p>000 Success</p> <p>100 Failed</p>

Get WiFi Parameters

Command Name	Get WiFi Parameters
Command URL	http://<Camera IP>/form/getWlan
Parameters	Null
Description	Get WiFi parameters
Response	<p>000 Success 100 Failed</p> <p>ENABLE=<value> Enable/Disable WiFi function, valid value is: 0 – Disable Disabled WiFi function 1 – Enable Enabled WiFi function</p> <p>SSID=<value> SSID of WiFi, valid value is: 1~32 character</p> <p>MODE=<value> WiFi type, valid value is: ADHOC - Adhoc mode INFRA – Infrastructure mode</p> <p>SECURITY=<value> Security type of WiFi, valid value is: OFF – Off WEP64 – WEP 64bit WEP128 – WEP 128bit WPA-PSK – WPA-PSK WPA2-PSK – WPA2-PSK</p> <p>ENCRYPTION=<value> Encryption type of WPA KEY, valid value is: TKIP – TKIP for WPA/WPA2 AES – AES for WPA/WPA2</p> <p>AUTHTYPE=<value> WEP authentication type, valid value is: AUTO – Automatically select Open System or Shared Key OPEN – Open System SHARED – Shared Key</p> <p>KEYTYPE=<value> WEP Key format, valid value is: ASCII – Ascii type key HEX – Hex type key</p> <p>WEPIDX=<value></p>

	<p>WEP Key index, valid value is: 1 ~ 4</p> <p>WEPKEY=<value></p> <p>WEP Key, valid value is: 5 character - for WEP64bit ASCII 10 character - for WEP64bit HEX 13 character - for WEP128bit ASCII 26 character - for WEP128bit HEX</p> <p>WPAKEY=<value></p> <p>WPA Key, valid value is: 8~64 character</p>
--	---

Set WiFi Parameters

Command Name	Set WiFi Parameters
Command URL	http://<Camera IP>/form/setWlan?<Param1>&<Param2>& ...
Parameters	<p>ENAB LE=<value> Enable/Disable WiFi function, valid value is: 0 – Disable Disabled WiFi function 1 – Enable Enabled WiFi function</p> <p>SSID=<value> SSID of WiFi, valid value is: 1~32 character</p> <p>MODE=<value> WiFi type, valid value is: ADHOC - Adhoc mode INFRA – Infrastructure mode</p> <p>SECURITY=<value> Security type of WiFi, valid value is: OFF – Off WEP64 – WEP 64bit WEP128 – WEP 128bit WPA-PSK – WPA-PSK WPA2-PSK – WPA2-PSK</p> <p>ENCRYPTION=<value> Encryption type of WPA KEY, valid value is: TKIP – TKIP for WPA/WPA2 AES – AES for WPA/WPA2</p> <p>AUTHTYPE=<value> WEP authentication type, valid value is: AUTO – Automatically select Open System or Shared Key OPEN – Open System SHARED – Shared Key</p> <p>KEYTYPE=<value> WEP Key format, valid value is: ASCII – AscII type key HEX – Hex type key</p> <p>WEPIDX=<value> WEP Key index, valid value is: 1 ~ 4</p> <p>WEPKEY=<value> WEP Key, valid value is: 5 character - for WEP64bit ASCII</p>

	10 character - for WEP64bit HEX 13 character - for WEP128bit ASCII 26 character - for WEP128bit HEX WPAKEY=<value> WPA Key, valid value is: 8-64 character
Description	Set WiFi parameters
Response	000 Success 100 Failed

Get WiFi Status

Command Name	Get WiFi Status
Command URL	http://<Camera IP>/form/getWlanStatus
Parameters	Null
Description	Get WiFi status
Response	<p>000 Success 100 Failed</p> <p>LINK=<value> Link Status, valid value is: 0 – No connection 1 – Connected</p> <p>SSID=<value> Wireless SSID name</p> <p>MODE=<value> Wireless mode, valid value is: ADHOC – Adhoc mode INFRA – Infrastructure mode</p> <p>CHANNEL=<value> Current wireless channel</p> <p>FREQ=<value> Current wireless frequency, valid value is: 2.4120G 2.4170G 2.4220G 2.4270G 2.4320G 2.4370G 2.4420G 2.4470G 2.4520G 2.4570G 2.4620G 2.4670G 2.4720G 2.4770G</p> <p>QUALITY= <value> Signal quality of essid, valid value is: 0 ~ 100</p> <p>SECURITY= <value></p>

	<p>Wireless security mode, valid value is:</p> <ul style="list-style-type: none">OFF – OffWEP64 – WEP 64bitWEP128 – WEP 128bitWPA-PSK – WPA-PSKWPA2-PSK – WPA2-PSK <p>IPMODE=<value></p> <p>The type of getting IP address, valid value is:</p> <ul style="list-style-type: none">DYNAMIC – Obtain an IP address automatically(DHCP)STATIC – Use static IP address <p>IPADDR=<value></p> <p>IP address, valid value is: IP address data</p> <p>NETMASK=<value></p> <p>Subnet mask, valid value is: IP address data</p> <p>GATEWAY=<value></p> <p>Gateway, valid value is: IP address data or empty</p> <p>DNS1=<value></p> <p>Primary DNS IP address, valid value is: IP address data or empty</p> <p>DNS2=<value></p> <p>Secondary DNS IP address, valid value is: IP address data or empty</p>
--	---

Wifi Test

Command Name	Wifi Test
Command URL	http://<Camera IP>/form/wlanTestStart
Parameters	Null
Description	Wifi Test
Response	000 Success 100 Failed

Get Wifi Test Status

Command Name	Get Wifi Test Status
Command URL	http://<Camera IP>/form/getWlanTestStatus
Parameters	Null
Description	Wifi Test Status
Response	000 Success 100 Failed 101 Busy

Wifi Scan

Command Name	Wifi Scan
Command URL	http://<Camera IP>/form/wlanScan
Parameters	Null
Description	Wifi Scan
Response	000 Success 100 Failed

Get Wifi List

Command Name	Get Wifi List
Command URL	http://<Camera IP>/form/getWlanList
Parameters	Null
Description	Get wifi list
Response	<p>000 Success 001 Busy 100 Failed</p> <p>NUM=<value> Number of essid</p> <p>ADDRESS0=<value> Address of essid0</p> <p>Protocol0=<value> Protocol of essid0</p> <p>ESSID0=<value> Name of essid0</p> <p>MODE0=<value> Mode of essid0, valid value is: Ad-Hoc Managed</p> <p>QUALITY0=<value> Signal quality of essid0, valid value is: 0 ~ 100</p> <p>AUTH0=<value> Auth mode of essid0, valid value is: OPEN WPAPSK WPA2PSK</p> <p>ENCRYPT0=<value> Encrypt mode of essid0, valid value is: NONE WEP TKIP AES TKIP/AES</p> <p>...</p> <p>...</p>

Get Ethernet Status

Command Name	Get Ethernet Status
Command URL	http://<Camera IP>/form/getEthernetStatus
Parameters	Null
Description	Get ethernet status
Response	000 Success 100 Failed LINK=<value> Link Status, valid value is: 0 – No connection 1 – Connected

Get TCP/IP Parameters

Command Name	Get TCP/IP Parameters
Command URL	http://<Camera IP>/form/getTcpip
Parameters	Null
Description	Get TCP/IP parameters
Response	<p>000 Success 100 Failed</p> <p>PROTO=<value> The type of getting IP address, valid value is: DHCP – Obtain an IP address automatically(DHCP) STATIC –Use static IP address</p> <p>IPADDR=<value> IP address, valid value is: IP address data</p> <p>NETMASK=<value> Subnet mask, valid value is: IP address data</p> <p>GATEWAY=<value> Gateway, valid value is: IP address data or empty</p> <p>DNSPROTO=<value> The type of getting DNS Server IP address, valid value is: DYNAMIC – Obtain DNS server address automatically STATIC – Use static DNS server address</p> <p>DNS1=<value> Primary DNS IP address, valid value is: IP address data or empty</p> <p>DNS2=<value> Secondary DNS IP address, valid value is: IP address data or empty</p>

Set TCP/IP Parameters

Command Name	Set TCP/IP Parameters
Command URL	http://<Camera IP>/form/setTcpip?<Param1>&<Param2>& ...
Parameters	<p>PROTO=<value> The type of getting IP address, valid value is: DHCP – Obtain an IP address automatically(DHCP) STATIC –Use static IP address</p> <p>IPADDR=<value> IP address, valid value is: IP address data</p> <p>NETMASK=<value> Subnet mask, valid value is: IP address data</p> <p>GATEWAY=<value> Gateway, valid value is: IP address data or empty</p> <p>DNSPROTO=<value> The type of getting DNS Server IP address, valid value is: DYNAMIC – Obtain DNS Server address automatically STATIC – Use static DNS server address</p> <p>DNS1=<value> Primary DNS IP address, valid value is: IP address data or empty</p> <p>DNS2=<value> Secondary DNS IP address, valid value is: IP address data or empty</p>
Description	Set TCP/IP parameters
Response	<p>000 Success</p> <p>100 Failed</p>

Get TCP/IP Status

Command Name	Get TCP/IP Status
Command URL	http://<Camera IP>/form/getTcpipStatus
Parameters	Null
Description	Get TCP/IP status
Response	<p>000 Success 100 Failed</p> <p>PROTO=<value> The type of getting IP address, valid value is: DHCP – Obtain an IP address automatically(DHCP) STATIC – Use static IP address</p> <p>IPADDR=<value> IP address, valid value is: IP address data</p> <p>NETMASK=<value> Subnet mask, valid value is: IP address data</p> <p>GATEWAY=<value> Gateway, valid value is: IP address data or empty</p> <p>DNS1=<value> Primary DNS IP address, valid value is: IP address data or empty</p> <p>DNS2=<value> Secondary DNS IP address, valid value is: IP address data or empty</p>

Get HTTP Port

Command Name	Get HTTP Port
Command URL	http://<Camera IP>/form/getHttpPort
Parameters	Null
Description	Get HTTP port
Response	000 Success 100 Failed PORT=<value> HTTP port number, valid value is: 1~65535

Set HTTP Port

Command Name	Set HTTP Port
Command URL	http://<Camera IP>/form/setHttpPort?<Param1>&<Param2>& ...
Parameters	PORT=<value> HTTP port number, valid value is: 1~65535
Description	Set HTTP port
Response	000 Success 100 Failed

Get RTP Port Range

Command Name	Get RTP Port range
Command URL	http://<Camera IP>/form/getRtpPort
Parameters	Null
Description	Get RTP port range
Response	000 Success 100 Failed RTPPORTSTART=<value> Min RTP port range, valid value is: 1~65535 RTPPORTEND=<value> Max RTP port range, valid value is: 1~65535

Set RTP Port Range

Command Name	Set RTP Port Range
Command URL	http://<Camera IP>/form/setRtpPort?<Param1>&<Param2>& ...
Parameters	RTPPORTSTART=<value> Min RTP port range, valid value is: 1~65535 RTPPORTEND=<value> Max RTP port range, valid value is: 1~65535
Description	Set RTP port range
Response	000 Success 100 Failed

Get DDNS Parameters

Command Name	Get DDNS Parameters
Command URL	http://<Camera IP>/form/getDdns
Parameters	Null
Description	Get DDNS parameters
Response	<p>000 Success</p> <p>100 Failed</p> <p>ENABLE=<value> Enable or disable DDNS function, valid value is: 0 – Disable DDNS 1 – Enable DDNS</p> <p>PROVIDER=<value> DDNS provider, valid value is: dtdns.com dyndns.org no-ip.com 3322.org</p> <p>HOSTNAME=<value> Hostname you register, valid value is: 0-128 characters</p> <p>USERNAME=<value> User name you register, valid value is: 0-128 characters</p> <p>PASSWORD=<value> Password you register, valid value is: 0-128 characters</p>

Set DDNS Parameters

Command Name	Set DDNS Parameters
Command URL	http://<Camera IP>/form/setDdns?<Param1>&<Param2>& ...
Parameters	<p>ENABLE=<value> Enable or disable DDNS function, valid value is: 0 – Disable DDNS 1 – Enable DDNS</p> <p>PROVIDER=<value> DDNS provider, valid value is: dtdns.com dyndns.org no-ip.com 3322.org</p> <p>HOSTNAME=<value> Hostname you register, valid value is: 0-128 characters</p> <p>USERNAME=<value> User name you register, valid value is: 0-128 characters</p> <p>PASSWORD=<value> Password you register, valid value is: 0-128 characters</p>
Description	Set DDNS parameters
Response	<p>000 Success</p> <p>100 Failed</p>

Get DDNS Status

Command Name	Get DDNS Status
Command URL	http://<Camera IP>/form/getDdnsStatus
Parameters	Null
Description	Get DDNS status
Response	000 Success 100 Failed STATUS=<value> DDNS status, valid value is: 0 – DDNS function is disabled 1 – DDNS is updating 2 – DDNS updated successfully

Get UPnP Parameters

Command Name	Get UPnP Parameters
Command URL	http://<Camera IP>/form/getUpnp
Parameters	Null
Description	Get UPnP parameters
Response	<p>000 Success</p> <p>100 Failed</p> <p>ENABLE=<value> Enable or disable UPnP function, valid value is: 0 – Disable UPnP 1 – Enable UPnP</p> <p>HTTPPORTFORWARD=<value> Enable or disable gateway HTTP/RTSP port forwarding, valid value is: 0 – Disable 1 – Enable</p> <p>MINEXTHTTPPORT=<value> Min external HTTP port range of router, valid value is: 1~65535</p> <p>MAXEXTHTTPPORT=<value> Max external HTTP port range of router, valid value is: 1~65535</p> <p>RTPPORTFORWARD=<value> Enable or disable gateway RTP port forwarding, valid value is: 0 – Disable 1 – Enable</p>

Set UPnP Parameters

Command Name	Set UPnP Parameters
Command URL	http://<Camera IP>/form/setUpnp?<Param1>&<Param2>& ...
Parameters	<p>ENABLE=<value> Enable or disable UPnP function, valid value is: 0 – Disable UPnP 1 – Enable UPnP</p> <p>HTTPPORTFORWARD=<value> Enable or disable gateway HTTP/RTSP port forwarding, valid value is: 0 – Disable 1 – Enable</p> <p>MINEXTHTTPPORT=<value> Min external HTTP port range of router, valid value is: 1~65535</p> <p>MAXEXTHTTPPORT=<value> Max external HTTP port range of router, valid value is: 1~65535</p> <p>RTPPORTFORWARD=<value> Enable or disable gateway RTP port forwarding, valid value is: 0 – Disable 1 – Enable</p>
Description	Set UPnP parameters
Response	<p>000 Success</p> <p>100 Failed</p>

Get UPnP Status

Command Name	Get UPnP Status
Command URL	http://<Camera IP>/form/getUpnpStatus
Parameters	Null
Description	Get UPnP status
Response	<p>000 Success 100 Failed</p> <p>STATUS=<value> UPnP Status, valid value is: 0 – UPnP function is disabled 1 – Can’t find any router or gateway 2 – Found router or gateway</p> <p>EXTIPADDR=<value> Router Internet IP address, valid value is: IP address data</p> <p>EXTPORT=<value> Router external port which is port forwarding to camera, valid value is: 0~65535</p>

Get RTHP Parameters (still unsupported)

Command Name	Get RTHP Parameters
Command URL	http://<Camera IP>/form/getRthpd
Parameters	Null
Description	Get RTHP parameters
Response	000 Success 100 Failed ENABLE=<value> Enable or disable RTHP function, valid value is: 0 – Disable RTHP 1 – Enable RTHP SERVER=<value> Host name of RTHP server valid value is: 0-128 characters PORT=<value> Port number, valid value is: 1-65535

Set RTHP Parameters (still unsupported)

Command Name	Set RTHP Parameters
Command URL	http://<Camera IP>/form/setRthpd?<Param1>&<Param2>& ...
Parameters	ENABLE=<value> Enable or disable RTHP function, valid value is: 0 – Disable RTHP 1 – Enable RTHP SERVER=<value> Host name of RTHP server valid value is: 0-128 characters PORT=<value> Port number, valid value is: 1~65535
Description	Set RTHP parameters
Response	000 Success 100 Failed

Get Storage Parameters

Command Name	Get Storage Parameters
Command URL	http://<Camera IP>/form/getStorage
Parameters	Null
Description	Get storage parameters
Response	<p>000 Success 100 Failed</p> <p>ENABLE=<value> Enable/Disable storage function, valid value is: 0 – Disable Disabled Storage function 1 – Enable Enabled Storage function</p> <p>DEVICE =<value> Select which storage device, valid value is: nas – Select NAS as storage device sd – Select SD card as storage device</p> <p>NASPATH=<value> NAS Path such as //192.168.168.50/ipcam_files, valid value is: 0-128 characters</p> <p>NASAUTH=<value> NAS needs authentication or not, valid value is: 0 – need not authentication 1 – needs authentication</p> <p>NASUSERNAME=<value> User name of NAS, valid value is: 0-128 characters</p> <p>NASPASSWORD=<value> Password of NAS, valid value is: 0-128 characters</p> <p>DIRECTORY=<value> Store directory, valid value is: 0-128 characters</p> <p>MAXSPACE=<value> (UNSUPPORTED AT THIS TIME, DO NOT USE) Max store space, valid value is: 0 – Unlimited 1000 – 1GB 2000 – 2GB 4000 – 4GB 8000 – 8GB</p>

16000 – 16GB

32000 – 32GB

64000 – 64GB

128000 – 128GB

256000 – 256GB

512000 – 512GB

1024000 – 1TB

MAXFILES=<value>

Max store files, valid value is:

0 – Unlimited

1000 – 1000 files

2000 – 2000 files

3000 – 3000 files

4000 – 4000 files

5000 – 5000 files

(VALUES LARGER THAN 5000 are UNSUPPORTED)

10000 – 10000 files

20000 – 20000 files

Set Storage Parameters

Command Name	Set Storage Parameters
Command URL	http://<Camera IP>/form/setStorage?<Param1>&<Param2>& ...
Parameters	<p>ENABLE=<value> Enable/Disable storage function, valid value is: 0 – Disable Disabled Storage function 1 – Enable Enabled Storage function</p> <p>DEVICE =<value> Select which storage device, valid value is: nas – Select NAS as storage device sd – Select SD card as storage device</p> <p>NASPATH=<value> NAS Path such as //192.168.168.50/ipcam_files, valid value is: 0-128 characters</p> <p>NASAUTH=<value> NAS needs authentication or not, valid value is: 0 – need not authentication 1 – needs authentication</p> <p>NASUSERNAME=<value> User name of NAS, valid value is: 0-128 characters</p> <p>NASPASSWORD=<value> Password of NAS, valid value is: 0-128 characters</p> <p>DIRECTORY=<value> Store directory, valid value is: 0-128 characters</p> <p>MAXSPACE=<value> (UNSUPPORTED AT THIS TIME, DO NOT USE) Max store space, valid value is: 0 – Unlimited 1000 – 1GB 2000 – 2GB 4000 – 4GB 8000 – 8GB 16000 – 16GB 32000 – 32GB 64000 – 64GB 128000 – 128GB 256000 – 256GB</p>

	512000 – 512GB 1024000 – 1TB MAXFILES=<value> Max store files, valid value is: 0 – Unlimited 1000 – 1000 files 2000 – 2000 files 3000 – 3000 files 4000 – 4000 files 5000 – 5000 files (VALUES LARGER THAN 5000 are UNSUPPORTED) 10000 – 10000 files 20000 – 20000 files
Description	Set storage parameters
Response	000 Success 100 Failed

Get Storage Status

Command Name	Get SD Card Status
Command URL	http://<Camera IP>/form/getStorageStatus
Parameters	Null
Description	Get Storage Status
Response	<p>000 Success 100 Failed</p> <p>ENABLE=<value> Enable/Disable storage function, valid value is: 0 – Disable Disabled Storage function 1 – Enable Enabled Storage function</p> <p>DEVICE =<value> Select which storage device, valid value is: nas – Select NAS as storage device sd – Select SD card as storage device</p> <p>READY=<value> valid value is: yes – storage device is ready no – storage device is not ready</p> <p>TOTAL=<value> Megabytes of total storage space</p> <p>USED=<value> Megabytes already used</p> <p>AVAILABLE=<value> Megabytes still available</p>

Get Storage File List

Command Name	Get Storage File List
Command URL	http://<Camera IP>/form/getStorageFileList
Parameters	<p>TYPE=<value> valid value is: 0 – All files 1 – Alarm Snapshot 2 – Periodic Snapshot 3 – Alarm Recording 4 – Continuous Recording</p>
Description	Get storage file list
Response	<p>000 Success 100 Failed</p> <p>NUM=<value> Number of files NAME0=<value> Name of file0 SIZE0=<value> Size of file0 NAME1=<value> Name of file1 SIZE1=<value> Size of file1 </p>

SD Card Format

Command Name	SD Card Format
Command URL	http://<Camera IP>/form/sdFormat
Parameters	Null
Description	Format SD card
Response	000 Success 100 Failed

Get SD Card Format Status

Command Name	Get SD Card Format Status
Command URL	http://<Camera IP>/form/getSdFormatStatus
Parameters	Null
Description	Get SD card format status
Response	000 Success 100 Failed 101 Busy

Get Digital I/O Parameters

Command Name	Get Digital I/O Parameters
Command URL	http://<Camera IP>/form/getDigitalIo
Parameters	Null
Description	Get Digital I/O Parameters
Response	<p>000 Success 100 Failed</p> <p>INPUT=<value> Enable or disable digital input function, valid value is: 0 – Disable digital input 1 – Enable digital input</p> <p>INPUTACTIVE=<value> Digital input's active state, valid value is: 0 – Low 1 – High</p> <p>OUTPUT=<value> Enable or disable digital output function, valid value is: 0 – Disable digital output 1 – Enable digital output</p> <p>OUTPUTACTIVE=<value> Digital output's active state, valid value is: 0 – Open 1 – Grounded</p>

Set Digital I/O Parameters

Command Name	Set Digital I/O Parameters
Command URL	http://<Camera IP>/form/setDigitalIo?<Param1>&<Param2>& ...
Parameters	<p>INPUT=<value> Enable or disable digital input function, valid value is: 0 – Disable digital input 1 – Enable digital input</p> <p>INPUTACTIVE=<value> Digital input's active state, valid value is: 0 – Low 1 – High</p> <p>OUTPUT=<value> Enable or disable digital output function, valid value is: 0 – Disable digital output 1 – Enable digital output</p> <p>OUTPUTACTIVE=<value> Digital output's active state, valid value is: 0 – Open 1 – Grounded</p>
Description	Set digital I/O parameters
Response	<p>000 Success</p> <p>100 Failed</p>

Get Motion Detection Parameters

Command Name	Get Motion Detection Parameters
Command URL	http://<Camera IP>/form/getMotion
Parameters	<p>WINDOW=<value> Window number, valid value is: 1~4</p>
Description	Get Motion detection parameters
Response	<p>000 Success 100 Failed</p> <p>WINDOW=<value> Window number, valid value is: 1~4</p> <p>ENABLE=<value> Enable or disable motion detection of this window, valid value is: 0 – Disable motion detection 1 – Enable motion detection</p> <p>TOP=<value> Top coordinate, valid value is: 0~479</p> <p>LEFT=<value> Left coordinate, valid value is: 0~639</p> <p>BOTTOM=<value> Bottom coordinate, valid value is: 0~479</p> <p>RIGHT=<value> Right coordinate, valid value is: 0~639</p> <p>THRESHOLD=<value> Threshold of motion detection, valid value is: 1~100</p> <p>SENSITIVITY=<value> Sensitivity of motion detection, valid value is: 1~100</p>

Set Motion Detection Parameters

Command Name	Set Motion Detection Parameters
Command URL	http://<Camera IP>/form/setMotion?<Param1>&<Param2>& ...
Parameters	<p>WINDOW=<value> Window number, valid value is: 1~4</p> <p>ENABLE=<value> Enable or disable motion detection of this window, valid value is: 0 – Disable motion detection 1 – Enable motion detection</p> <p>TOP=<value> Top coordinate, valid value is: 0~479</p> <p>LEFT=<value> Left coordinate, valid value is: 0~639</p> <p>BOTTOM=<value> Bottom coordinate, valid value is: 0~479</p> <p>RIGHT=<value> Right coordinate, valid value is: 0~639</p> <p>THRESHOLD=<value> Threshold of motion detection, valid value is: 1~100</p> <p>SENSITIVITY=<value> Sensitivity of motion detection, valid value is: 1~100</p>
Description	Set motion detection parameters
Response	<p>000 Success</p> <p>100 Failed</p>

Get Schedule Parameters

Command Name	Get Schedule Parameters
Command URL	http://<Camera IP>/form/getSchedule
Parameters	<p>ID=<value> Schedule ID, valid value is: 1~4</p>
Description	Get schedule parameters
Response	<p>000 Success 100 Failed</p> <p>ID=<value> Schedule ID, valid value is: 1~4</p> <p>ENABLE<n>=<value> Enable or disable schedule time, valid value is: 0 – Disable 1 – Enable</p> <p>SCHEDTYPE<n>=<value> Schedule type, valid value is: 0 – Week mode 1 – Date mode</p> <p>STARTHOUR<n>=<value> Start time hour, valid value is: 0~24</p> <p>STARTMIN<n>=<value> Start time minute, valid value is: 0~59</p> <p>ENDHOUR<n>=<value> End time hour, valid value is: 0~24</p> <p>ENDMIN<n>=<value> End time minute, valid value is: 0~59</p> <p>DAYS<n>=<value> Bit0 – Sunday Bit1 – Monday Bit2 – Tuesday Bit3 – Wednesday Bit4 –Thursday Bit5 – Friday</p>

	<p>Bit6 – Saturday</p> <p>DATE<n>=<value> YYYYMMDD</p> <p>Note: <n> Rule index, valid value is:0-7</p>	
--	--	--

Set Schedule Parameters

Command Name	Set Schedule Parameters
Command URL	http://<Camera IP>/form/setSchedule?<Param1>&<Param2>& ...
Parameters	<p>ID=<value> Schedule ID, valid value is: 1-4</p> <p>ENABLE<n>=<value> Enable or disable schedule time, valid value is: 0 – Disable 1 – Enable</p> <p>SCHEDTYPE<n>=<value> Schedule type, valid value is: 0 – Week mode 1 – Date mode</p> <p>STARTHOUR<n>=<value> Start time hour, valid value is: 0-24</p> <p>STARTMIN<n>=<value> Start time minute, valid value is: 0-59</p> <p>ENDHOUR<n>=<value> End time hour, valid value is: 0-24</p> <p>ENDMIN<n>=<value> End time minute, valid value is: 0-59</p> <p>DAYS<n>=<value> Bit0 – Sunday Bit1 – Monday Bit2 – Tuesday Bit3 – Wednesday Bit4 –Thursday Bit5 – Friday Bit6 – Saturday</p> <p>DATE<n>=<value> YYYYMMDD</p> <p>Note: <n> Rule index, valid value is:0-7</p>
Description	Set schedule parameters

Response	000 Success 100 Failed
-----------------	---

Get EMail Alarm Sending Parameters

Command Name	Get EMail Alarm Sending Parameters
Command URL	http://<Camera IP>/form/getEmailAlarmSending
Parameters	Null
Description	Get EMail Alarm Sending Parameters
Response	<p>000 Success 100 Failed</p> <p>ENABLE=<value> Enable or Disable function, valid value is: 0 – Disable 1 – Enable</p> <p>SCHED=<value> Select schedule for Effective period or not, valid value is: 0 – Do not select schedule 1 – Select schedule</p> <p>SCHEDID=<value> Select schedule ID, valid value is: 1~4</p> <p>STREAMID=<value> Select which stream be used when snapshot, valid value is: 0 – Primary stream 1 – Secondary stream 2 – Mobile stream</p> <p>DURATION=<value> How long to keep sending images after alarm, valid value is: 1~20 seconds</p> <p>FRAMERATE=<value> How many images to be sent to per second after alarm, valid value is: 1~5 images/sec</p> <p>INTERVAL=<value> Alarm Interval of Email Alarm Sending, Valid Value is: 0~86400 (0: not limited)</p> <p>SERVER=<value> SMTP Server name or IP address, Valid Value is: 0~64 characters</p> <p>PORT=<value> SMTP port number, Valid Value is: 1~65535</p>

	<p>SSL=<value> SMTP Server uses Secure SSL connection or not, Valid Value is: 0 – don't use Secure SSL connection 1 – use Secure SSL connection</p> <p>AUTH=<value> SMTP Server needs authentication or not, Valid Value is: 0 – no authentication 1 – needs authentication</p> <p>USERNAME=<value> Login user name, Valid Value is: 0~64 characters</p> <p>PASSWORD=<value> Login password, Valid Value is: 0~128 characters</p> <p>SENDER=<value> Sender Email address, Valid Value is: 0~64 characters</p> <p>RECEIVER1=<value> Receiver Email address 1, Valid Value is: 0~192 characters</p> <p>RECEIVER2=<value> Receiver Email address 2, Valid Value is: 0~192 characters</p> <p>RECEIVER3=<value> Receiver Email address 3, Valid Value is: 0~192 characters</p> <p>SUBJECT=<value> Email subject, Valid Value is: 0~128 characters</p> <p>MESSAGE=<value> Email content, Valid Value is: 0~128 characters</p>
--	---

Set EMail Alarm Sending Parameters

Command Name	Set EMail Alarm Sending Parameters
Command URL	http://<Camera IP> /form/setEmailAlarmSending?<Param1>&<Param2>& ...
Parameters	<p>ENABLE=<value> Enable or Disable function, valid value is: 0 – Disable 1 – Enable</p> <p>SCHED=<value> Select schedule for Effective period or not, valid value is: 0 – Do not select schedule 1 – Select schedule</p> <p>SCHEDID=<value> Select schedule ID, valid value is: 1~4</p> <p>STREAMID=<value> Select which stream to be used for snapshot, valid value is: 0 – Primary stream 1 – Secondary stream 2 – Mobile stream</p> <p>DURATION=<value> How long to keep sending images after alarm, valid value is: 1~20 seconds</p> <p>FRAMERATE=<value> How many images to be sent per second after alarm, valid value is: 1~5 images/sec</p> <p>INTERVAL=<value> Alarm Interval of Email Alarm Sending, Valid Value is: 0~86400 (0: no limit)</p> <p>SERVER=<value> SMTP Server name or IP address, Valid Value is: 0~64 characters</p> <p>PORT=<value> SMTP port number, Valid Value is: 1~65535</p> <p>SSL=<value> SMTP Server uses Secure SSL connection or not, Valid Value is: 0 – don't use Secure SSL connection 1 – use Secure SSL connection</p> <p>AUTH=<value></p>

	<p>SMTP Server needs authentication or not, Valid Value is: 0 – no authentication 1 – needs authentication</p> <p>USERNAME=<value> Login user name, Valid Value is: 0~64 characters</p> <p>PASSWORD=<value> Login password, Valid Value is: 0~128 characters</p> <p>SENDER=<value> Sender Email address, Valid Value is: 0~64 characters</p> <p>RECEIVER1=<value> Receiver Email address 1, Valid Value is: 0~192 characters</p> <p>RECEIVER2=<value> Receiver Email address 2, Valid Value is: 0~192 characters</p> <p>RECEIVER3=<value> Receiver Email address 3, Valid Value is: 0~192 characters</p> <p>SUBJECT=<value> Email subject, Valid Value is: 0~128 characters</p> <p>MESSAGE=<value> Email content, Valid Value is: 0~128 characters</p>
Description	Set Email Alarm Sending Parameters of Camera
Response	<p>000 Success</p> <p>100 Failed</p>

Get EMail Periodic Sending Parameters

Command Name	Get EMail Periodic Sending Parameters
Command URL	http://<Camera IP>/form/getEmailPeriodSending
Parameters	Null
Description	Get EMail Periodic Sending Parameters
Response	<p>000 Success</p> <p>100 Failed</p> <p>ENABLE=<value> Enable or Disable function, valid value is: 0 – Disable 1 – Enable</p> <p>SCHED=<value> Select schedule for Effective period or not, valid value is: 0 – Do not select schedule 1 – Select schedule</p> <p>SCHEDID=<value> Select schedule ID, valid value is: 1~4</p> <p>HOUR=<value> Interval time hour, valid value is: 0~24</p> <p>MIN=<value> Interval time minute, valid value is: 0~59</p> <p>SEC=<value> Interval time second, valid value is: 0~59</p> <p>STREAMID=<value> Select which stream to use for snapshot, valid value is: 0 – Primary stream 1 – Secondary stream 2 – Mobile stream</p> <p>DURATION=<value> How long to send images after alarm, valid value is: 1~20 seconds</p> <p>FRAMERATE=<value> How many images to be sent to server per second after alarm, valid value is: 1~5 images/sec</p>

	<p>SERVER=<value> SMTP Server name or IP address, Valid Value is: 0~64 characters</p> <p>PORT=<value> SMTP port number, Valid Value is: 1~65535</p> <p>SSL=<value> SMTP Server uses Secure SSL connection or not, Valid Value is: 0 – don't use Secure SSL connection 1 – use Secure SSL connection</p> <p>AUTH=<value> SMTP Server needs authentication or not, Valid Value is: 0 – no authentication 1 – needs authentication</p> <p>USERNAME=<value> Login user name, Valid Value is: 0~64 characters</p> <p>PASSWORD=<value> Login password, Valid Value is: 0~128 characters</p> <p>SENDER=<value> Sender Email address, Valid Value is: 0~64 characters</p> <p>RECEIVER1=<value> Receiver Email address 1, Valid Value is: 0~192 characters</p> <p>RECEIVER2=<value> Receiver Email address 2, Valid Value is: 0~192 characters</p> <p>RECEIVER3=<value> Receiver Email address 3, Valid Value is: 0~192 characters</p> <p>SUBJECT=<value> Email subject, Valid Value is: 0~128 characters</p> <p>MESSAGE=<value> Email content, Valid Value is: 0~128 characters</p>
--	---

Set EMail Periodic Sending Parameters

Command Name	Set EMail Periodic Sending Parameters
Command URL	http://<Camera IP> /form/setEmailPeriodSending?<Param1>&<Param2>& ...
Parameters	<p>ENABLE=<value> Enable or Disable function, valid value is: 0 – Disable 1 – Enable</p> <p>SCHED=<value> Select schedule for Effective period or not, valid value is: 0 – Do not select schedule 1 – Select schedule</p> <p>SCHEDID=<value> Select schedule ID, valid value is: 1~4</p> <p>HOUR=<value> Interval time hour, valid value is: 0~24</p> <p>MIN=<value> Interval time minute, valid value is: 0~59</p> <p>SEC=<value> Interval time second, valid value is: 0~59</p> <p>STREAMID=<value> Select which stream to use for snapshot, valid value is: 0 – Primary stream 1 – Secondary stream 2 – Mobile stream</p> <p>DURATION=<value> How long to send images after alarm, valid value is: 1~20 seconds</p> <p>FRAMERATE=<value> How many images to send per second after alarm, valid value is: 1~5 images/sec</p> <p>SERVER=<value> SMTP Server name or IP address, Valid Value is: 0~64 characters</p> <p>PORT=<value> SMTP port number, Valid Value is:</p>

	<p>1~65535</p> <p>SSL=<value> SMTP Server uses Secure SSL connection or not, Valid Value is: 0 – don't use Secure SSL connection 1 – use Secure SSL connection</p> <p>AUTH=<value> SMTP Server needs authentication or not, Valid Value is: 0 – no authentication 1 – needs authentication</p> <p>USERNAME=<value> Login user name, Valid Value is: 0~64 characters</p> <p>PASSWORD=<value> Login password, Valid Value is: 0~128 characters</p> <p>SENDER=<value> Sender Email address, Valid Value is: 0~64 characters</p> <p>RECEIVER1=<value> Receiver Email address 1, Valid Value is: 0~192 characters</p> <p>RECEIVER2=<value> Receiver Email address 2, Valid Value is: 0~192 characters</p> <p>RECEIVER3=<value> Receiver Email address 3, Valid Value is: 0~192 characters</p> <p>SUBJECT=<value> Email subject, Valid Value is: 0~128 characters</p> <p>MESSAGE=<value> Email content, Valid Value is: 0~128 characters</p>
Description	Set EMail Periodic Sending Parameters of Camera
Response	<p>000 Success</p> <p>100 Failed</p>

Get FTP Alarm Sending Parameters

Command Name	Get FTP Alarm Sending Parameters
Command URL	http://<Camera IP>/form/getFtpAlarmSending
Parameters	Null
Description	Get FTP Alarm Sending Parameters
Response	<p>000 Success 100 Failed</p> <p>ENABLE=<value> Enable or Disable function, valid value is: 0 – Disable 1 – Enable</p> <p>SCHED=<value> Select schedule for Effective period or not, valid value is: 0 – Do not select schedule 1 – Select schedule</p> <p>SCHEDID=<value> Select schedule ID, valid value is: 1~4</p> <p>STREAMID=<value> Select which stream to use for snapshot, valid value is: 0 – Primary stream 1 – Secondary stream 2 – Mobile stream</p> <p>DURATION=<value> How long to send images after alarm, valid value is: 1~20 seconds</p> <p>FRAMERATE=<value> How many images to send per second after alarm, valid value is: 1~5 images/sec</p> <p>INTERVAL=<value> Alarm Interval of FTP Alarm Sending, Valid Value is: 0~86400 (0: not limit)</p> <p>SERVER=<value> FTP Server name or IP address, Valid Value is: 0~64 characters</p> <p>PORT=<value> FTP Server port number, Valid Value is: 1~65535</p> <p>REMOTEPATH=<value></p>

	<p>Remote path of server, valid value is: 0~64 characters</p> <p>AUTH=<value></p> <p>FTP server needs authentication or not, Valid Value is: 0 – no authentication 1 – needs authentication</p> <p>USERNAME=<value></p> <p>Login user name, Valid Value is: 0~64 characters</p> <p>PASSWORD=<value></p> <p>Login password, Valid Value is: 0~128 characters</p>	
--	--	--

Set FTP Alarm Sending Parameters

Command Name	Set FTP Alarm Sending Parameters
Command URL	http://<Camera IP> /form/setFtpAlarmSending?<Param1>&<Param2>& ...
Parameters	<p>ENABLE=<value> Enable or Disable function, valid value is: 0 – Disable 1 – Enable</p> <p>SCHED=<value> Select schedule for Effective period or not, valid value is: 0 – Do not select schedule 1 – Select schedule</p> <p>SCHEDID=<value> Select schedule ID, valid value is: 1~4</p> <p>STREAMID=<value> Select which stream to use for snapshot, valid value is: 0 – Primary stream 1 – Secondary stream 2 – Mobile stream</p> <p>DURATION=<value> How long to send images after alarm, valid value is: 1~20 seconds</p> <p>FRAMERATE=<value> How many images to send per second after alarm, valid value is: 1~5 images/sec</p> <p>INTERVAL=<value> Alarm Interval of FTP Alarm Sending, Valid Value is: 0~86400 (0: not limit)</p> <p>SERVER=<value> FTP Server name or IP address, Valid Value is: 0~64 characters</p> <p>PORT=<value> FTP Server port number, Valid Value is: 1~65535</p> <p>REMOTEPATH=<value> Remote path of server, valid value is: 0~64 characters</p> <p>AUTH=<value> FTP server needs authentication or not, Valid Value is:</p>

	0 – no authentication 1 – needs authentication USERNAME=<value> Login user name, Valid Value is: 0-64 characters PASSWORD=<value> Login password, Valid Value is: 0-128 characters
Description	Set FTP Alarm Sending Parameters of Camera
Response	000 Success 100 Failed

Get FTP Periodic Sending Parameters

Command Name	Get FTP Periodic Sending Parameters
Command URL	http://<Camera IP>/form/getFtpPeriodSending
Parameters	Null
Description	Get FTP Periodic Sending Parameters
Response	<p>000 Success 100 Failed</p> <p>ENABLE=<value> Enable or Disable function, valid value is: 0 – Disable 1 – Enable</p> <p>SCHED=<value> Select schedule for Effective period or not, valid value is: 0 – Do not select schedule 1 – Select schedule</p> <p>SCHEDID=<value> Select schedule ID, valid value is: 1~4</p> <p>HOUR=<value> Interval time hour, valid value is: 0~24</p> <p>MIN=<value> Interval time minute, valid value is: 0~59</p> <p>SEC=<value> Interval time second, valid value is: 0~59</p> <p>STREAMID=<value> Select which stream to use for snapshot, valid value is: 0 – Primary stream 1 – Secondary stream 2 – Mobile stream</p> <p>DURATION=<value> How long to send images after alarm, valid value is: 1~20 seconds</p> <p>FRAMERATE=<value> How many images to send per second after alarm, valid value is: 1~5 images/sec</p> <p>SERVER=<value></p>

	<p>FTP Server name or IP address, Valid Value is: 0~64 characters</p> <p>PORT=<value></p> <p>FTP Server port number, Valid Value is: 1~65535</p> <p>REMOTEPATH=<value></p> <p>Remote path of server, valid value is: 0~64 characters</p> <p>AUTH=<value></p> <p>FTP server needs authentication or not, Valid Value is: 0 – no authentication 1 – needs authentication</p> <p>USERNAME=<value></p> <p>Login user name, Valid Value is: 0~64 characters</p> <p>PASSWORD=<value></p> <p>Login password, Valid Value is: 0~128 characters</p>
--	---

Set FTP Periodic Sending Parameters

Command Name	Set FTP Periodic Sending Parameters
Command URL	http://<Camera IP> /form/setFtpPeriodSending?<Param1>&<Param2>& ...
Parameters	<p>ENABLE=<value> Enable or Disable function, valid value is: 0 – Disable 1 – Enable</p> <p>SCHED=<value> Select schedule for Effective period or not, valid value is: 0 – Do not select schedule 1 – Select schedule</p> <p>SCHEDID=<value> Select schedule ID, valid value is: 1~4</p> <p>HOUR=<value> Interval time hour, valid value is: 0~24</p> <p>MIN=<value> Interval time minute, valid value is: 0~59</p> <p>SEC=<value> Interval time second, valid value is: 0~59</p> <p>STREAMID=<value> Select which stream to use for snapshot, valid value is: 0 – Primary stream 1 – Secondary stream 2 – Mobile stream</p> <p>DURATION=<value> How long to send images after alarm, valid value is: 1~20 seconds</p> <p>FRAMERATE=<value> How many images to send per second after alarm, valid value is: 1~5 images/sec</p> <p>SERVER=<value> FTP Server name or IP address, Valid Value is: 0~64 characters</p> <p>PORT=<value> FTP Server port number, Valid Value is:</p>

	<p>1~65535</p> <p>REMOTEPATH=<value> Remote path of server, valid value is: 0~64 characters</p> <p>AUTH=<value> FTP server needs authentication or not, Valid Value is: 0 – no authentication 1 – needs authentication</p> <p>USERNAME=<value> Login user name, Valid Value is: 0~64 characters</p> <p>PASSWORD=<value> Login password, Valid Value is: 0~128 characters</p>
Description	Set FTP Periodic Sending Parameters of Camera
Response	000 Success 100 Failed

Get HTTP Alarm Sending Parameters

Command Name	Get HTTP Alarm Sending Parameters
Command URL	http://<Camera IP>/form/getHttpAlarmSending
Parameters	Null
Description	Get HTTP Alarm Sending Parameters
Response	<p>000 Success 100 Failed</p> <p>ENABLE=<value> Enable or Disable function, valid value is: 0 – Disable 1 – Enable</p> <p>SCHED=<value> Select schedule for Effective period or not, valid value is: 0 – Do not select schedule 1 – Select schedule</p> <p>SCHEDID=<value> Select schedule ID, valid value is: 1~4</p> <p>INTERVAL=<value> Alarm Interval of HTTP Alarm Sending, Valid Value is: 0~86400 (0: not limit)</p> <p>URL=<value> Define sending URL, valid value is: 0~127 characters</p> <p>AUTH=<value> HTTP Server needs authentication or not, Valid Value is: 0 – no authentication 1 – needs authentication</p> <p>USERNAME=<value> Login user name, Valid Value is: 0~64 characters</p> <p>PASSWORD=<value> Login password, Valid Value is: 0~128 characters</p>

Set HTTP Alarm Sending Parameters

Command Name	Set HTTP Alarm Sending Parameters
Command URL	http://<Camera IP> /form/setHttpAlarmSending?<Param1>&<Param2>& ...
Parameters	<p>ENABLE=<value> Enable or Disable function, valid value is: 0 – Disable 1 – Enable</p> <p>SCHED=<value> Select schedule for Effective period or not, valid value is: 0 – Do not select schedule 1 – Select schedule</p> <p>SCHEDID=<value> Select schedule ID, valid value is: 1~4</p> <p>INTERVAL=<value> Alarm Interval of HTTP Alarm Sending, Valid Value is: 0~86400 (0: not limit)</p> <p>URL=<value> Define sending URL, valid value is: 0~127 characters</p> <p>AUTH=<value> HTTP Server needs authentication or not, Valid Value is: 0 – no authentication 1 – needs authentication</p> <p>USERNAME=<value> Login user name, Valid Value is: 0~64 characters</p> <p>PASSWORD=<value> Login password, Valid Value is: 0~128 characters</p>
Description	Set HTTP Alarm Sending Parameters of Camera
Response	000 Success 100 Failed

Get HTTP Periodic Sending Parameters

Command Name	Get HTTP Periodic Sending Parameters
Command URL	http://<Camera IP>/form/getHttpPeriodSending
Parameters	Null
Description	Get HTTP Periodic Sending Parameters
Response	<p>000 Success</p> <p>100 Failed</p> <p>ENABLE=<value> Enable or Disable function, valid value is: 0 – Disable 1 – Enable</p> <p>SCHED=<value> Select schedule for Effective period or not, valid value is: 0 – Do not select schedule 1 – Select schedule</p> <p>SCHEDID=<value> Select schedule ID, valid value is: 1~4</p> <p>HOUR=<value> Interval time hour, valid value is: 0~24</p> <p>MIN=<value> Interval time minute, valid value is: 0~59</p> <p>SEC=<value> Interval time second, valid value is: 0~59</p> <p>URL=<value> Define sending URL, valid value is: 0~127 characters</p> <p>AUTH=<value> HTTP Server needs authentication or not, Valid Value is: 0 – no authentication 1 – needs authentication</p> <p>USERNAME=<value> Login user name, Valid Value is: 0~64 characters</p> <p>PASSWORD=<value> Login password, Valid Value is:</p>

	0~128 characters
--	------------------

Set HTTP Periodic Sending Parameters

Command Name	Set HTTP Periodic Sending Parameters
Command URL	http://<Camera IP> /form/setHttpPeriodSending?<Param1>&<Param2>& ...
Parameters	<p>ENABLE=<value> Enable or Disable function, valid value is: 0 – Disable 1 – Enable</p> <p>SCHED=<value> Select schedule for Effective period or not, valid value is: 0 – Do not select schedule 1 – Select schedule</p> <p>SCHEDID=<value> Select schedule ID, valid value is: 1~4</p> <p>HOUR=<value> Interval time hour, valid value is: 0~24</p> <p>MIN=<value> Interval time minute, valid value is: 0~59</p> <p>SEC=<value> Interval time second, valid value is: 0~59</p> <p>URL=<value> Define sending URL, valid value is: 0~127 characters</p> <p>AUTH=<value> HTTP Server needs authentication or not, Valid Value is: 0 – no authentication 1 – needs authentication</p> <p>USERNAME=<value> Login user name, Valid Value is: 0~64 characters</p> <p>PASSWORD=<value> Login password, Valid Value is: 0~128 characters</p>
Description	Set HTTP Periodic Sending Parameters of Camera
Response	000 Success 100 Failed

Get Storage Alarm Snapshot Parameters

Command Name	Get Storage Alarm Snapshot Parameters
Command URL	http://<Camera IP>/form/getStorageAlarmSnapshot
Parameters	Null
Description	Get Storage Alarm Snapshot Parameters
Response	<p>000 Success</p> <p>100 Failed</p> <p>ENABLE=<value> Enable or Disable function, valid value is: 0 – Disable 1 – Enable</p> <p>SCHED=<value> Select schedule for Effective period or not, valid value is: 0 – Do not select schedule 1 – Select schedule</p> <p>SCHEDID=<value> Select schedule ID, valid value is: 1~4</p> <p>STREAMID=<value> Select which stream to use for snapshot, valid value is: 0 – Primary stream 1 – Secondary stream 2 – Mobile stream</p> <p>DURATION=<value> How long to send images after alarm, valid value is: 1~20 seconds</p> <p>FRAMERATE=<value> How many images to send per second after alarm, valid value is: 1~5 images/sec</p> <p>INTERVAL=<value> Alarm Interval of Email Alarm Sending, Valid Value is: 0~86400 (0: not limit)</p> <p>FILENAME=<value> Define file name of image, valid value is: 0~64 characters</p> <p>SUFFIX=<value> Select suffix of image file name, valid value is: 0 – Select serial number as suffix of file name 1 – Select time as suffix of file name</p>

Set Storage Alarm Snapshot Parameters

Command Name	Set Storage Alarm Snapshot Parameters
Command URL	http://<Camera IP> /form/setStorageAlarmSnapshot?<Param1>&<Param2>& ...
Parameters	<p>ENABLE=<value> Enable or Disable function, valid value is: 0 – Disable 1 – Enable</p> <p>SCHED=<value> Select schedule for Effective period or not, valid value is: 0 – Do not select schedule 1 – Select schedule</p> <p>SCHEDID=<value> Select schedule ID, valid value is: 1~4</p> <p>STREAMID=<value> Select which stream to use for snapshot, valid value is: 0 – Primary stream 1 – Secondary stream 2 – Mobile stream</p> <p>DURATION=<value> How long to send images after alarm, valid value is: 1~20 seconds</p> <p>FRAMERATE=<value> How many images to send per second after alarm, valid value is: 1~5 images/sec</p> <p>INTERVAL=<value> Alarm Interval of Email Alarm Sending, Valid Value is: 0~86400 (0: not limit)</p> <p>FILENAME=<value> Define file name of image, valid value is: 0~64 characters</p> <p>SUFFIX=<value> Select suffix of image file name, valid value is: 0 – Select serial number as suffix of file name 1 – Select time as suffix of file name</p>
Description	Set Storage Alarm Snapshot Parameters of Camera
Response	000 Success 100 Failed

Get Storage Periodic Snapshot Parameters

Command Name	Get Storage Periodic Snapshot Parameters
Command URL	http://<Camera IP>/form/getStoragePeriodSnapshot
Parameters	Null
Description	Get Storage Periodic Snapshot Parameters
Response	<p>000 Success</p> <p>100 Failed</p> <p>ENABLE=<value> Enable or Disable function, valid value is: 0 – Disable 1 – Enable</p> <p>SCHED=<value> Select schedule for Effective period or not, valid value is: 0 – Do not select schedule 1 – Select schedule</p> <p>SCHEDID=<value> Select schedule ID, valid value is: 1~4</p> <p>HOUR=<value> Interval time hour, valid value is: 0~24</p> <p>MIN=<value> Interval time minute, valid value is: 0~59</p> <p>SEC=<value> Interval time second, valid value is: 0~59</p> <p>STREAMID=<value> Select which stream to use for snapshot, valid value is: 0 – Primary stream 1 – Secondary stream 2 – Mobile stream</p> <p>DURATION=<value> How long to send images after alarm, valid value is: 1~20 seconds</p> <p>FRAMERATE=<value> How many images to send per second after alarm, valid value is: 1~5 images/sec</p> <p>FILENAME=<value></p>

	<p>Define file name of image, valid value is: 0-64 characters SUFFIX=<value> Select suffix of image file name, valid value is: 0 – Select serial number as suffix of file name 1 – Select time as suffix of file name</p>
--	--

Set Storage Periodic Snapshot Parameters

Command Name	Set Storage Periodic Snapshot Parameters
Command URL	http://<Camera IP> /form/setStoragePeriodSnapshot?<Param1>&<Param2>& ...
Parameters	<p>ENABLE=<value> Enable or Disable function, valid value is: 0 – Disable 1 – Enable</p> <p>SCHED=<value> Select schedule for Effective period or not, valid value is: 0 – Do not select schedule 1 – Select schedule</p> <p>SCHEDID=<value> Select schedule ID, valid value is: 1~4</p> <p>HOUR=<value> Interval time hour, valid value is: 0~24</p> <p>MIN=<value> Interval time minute, valid value is: 0~59</p> <p>SEC=<value> Interval time second, valid value is: 0~59</p> <p>STREAMID=<value> Select which stream to use for snapshot, valid value is: 0 – Primary stream 1 – Secondary stream 2 – Mobile stream</p> <p>DURATION=<value> How long to send images after alarm, valid value is: 1~20 seconds</p> <p>FRAMERATE=<value> How many images to send per second after alarm, valid value is: 1~5 images/sec</p> <p>FILENAME=<value> Define file name of image, valid value is: 0~64 characters</p> <p>SUFFIX=<value> Select suffix of image file name, valid value is:</p>

	0 – Select serial number as suffix of file name 1 – Select time as suffix of file name
Description	Set Storage Periodic Snapshot Parameters of Camera
Response	000 Success 100 Failed

Get Storage Alarm Recording Parameters

Command Name	Get Storage Alarm Recording Parameters
Command URL	http://<Camera IP>/form/getStorageAlarmRecord
Parameters	Null
Description	Get Storage Alarm Recording Parameters
Response	<p>000 Success 100 Failed</p> <p>ENABLE=<value> Enable or Disable function, valid value is: 0 – Disable 1 – Enable</p> <p>SCHED=<value> Select schedule for Effective period or not, valid value is: 0 – Do not select schedule 1 – Select schedule</p> <p>SCHEDID=<value> Select schedule ID, valid value is: 1~4</p> <p>STREAMID=<value> Select which stream to use for snapshot, valid value is: 0 – Primary stream 1 – Secondary stream 2 – Mobile stream</p> <p>DURATION=<value> How long to send images after alarm, valid value is: 1~20 seconds</p> <p>SPLITDURATION=<value> Maximum number of seconds per file before split.</p> <p>THUMBNAIL=<value> Enable or Disable record thumbnail, valid value is: 0 – Disable 1 – Enable</p> <p>FILENAME=<value> Define file name of recording file, valid value is: 0~64 characters</p> <p>SUFFIX=<value> Select suffix of image file name, valid value is: 1 – Select time as suffix of file name 2 – Select time and recording time as suffix of file name</p>

Set Storage Alarm Recording Parameters

Command Name	Set Storage Alarm Recording Parameters
Command URL	http://<Camera IP> /form/setStorageAlarmRecord?<Param1>&<Param2>& ...
Parameters	<p>ENABLE=<value> Enable or Disable function, valid value is: 0 – Disable 1 – Enable</p> <p>SCHED=<value> Select schedule for Effective period or not, valid value is: 0 – Do not select schedule 1 – Select schedule</p> <p>SCHEDID=<value> Select schedule ID, valid value is: 1~4</p> <p>STREAMID=<value> Select which stream to use for snapshot, valid value is: 0 – Primary stream 1 – Secondary stream 2 – Mobile stream</p> <p>DURATION=<value> How long to send images after alarm, valid value is: 1~20 seconds</p> <p>SPLITDURATION=<value> Maximum number of seconds per file before split.</p> <p>THUMBNAIL=<value> Enable or Disable record thumbnail, valid value is: 0 – Disable 1 – Enable</p> <p>FILENAME=<value> Define file name of recording file, valid value is: 0~64 characters</p> <p>SUFFIX=<value> Select suffix of image file name, valid value is: 1 – Select time as suffix of file name 2 – Select time and recording time as suffix of file name</p>
Description	Set Storage Alarm Recording Parameters
Response	000 Success 100 Failed

Get Storage Continuous Recording Parameters

Command Name	Get Storage Continuous Recording Parameters
Command URL	http://<Camera IP>/form/getStorageContinueRecord
Parameters	Null
Description	Get Storage Continuous Recording Parameters
Response	<p>000 Success 100 Failed</p> <p>ENABLE=<value> Enable or Disable function, valid value is: 0 – Disable 1 – Enable</p> <p>SCHED=<value> Select schedule for Effective period or not, valid value is: 0 – Do not select schedule 1 – Select schedule</p> <p>SCHEDID=<value> Select schedule ID, valid value is: 1~4</p> <p>STREAMID=<value> Select which stream to use for video, valid value is: 0 – Primary stream 1 – Secondary stream 2 – Mobile stream</p> <p>SPLITDURATION=<value> Maximum number of seconds per file before split.</p> <p>THUMBNAIL=<value> Enable or Disable record thumbnail, valid value is: 0 – Disable 1 – Enable</p> <p>FILENAME=<value> Define file name of recording file, valid value is: 0~64 characters</p> <p>SUFFIX=<value> Select suffix of image file name, valid value is: 1 – Select time as suffix of file name 2 – Select time and recording time as suffix of file name</p>

Set Storage Continuous Recording Parameters

Command Name	Set Storage Continuous Recording Parameters
Command URL	http://<Camera IP> /form/setStorageContinueRecord?<Param1>&<Param2>& ...
Parameters	<p>ENABLE=<value> Enable or Disable function, valid value is: 0 – Disable 1 – Enable</p> <p>SCHED=<value> Select schedule for Effective period or not, valid value is: 0 – Do not select schedule 1 – Select schedule</p> <p>SCHEDID=<value> Select schedule ID, valid value is: 1~4</p> <p>STREAMID=<value> Select which stream to use for video, valid value is: 0 – Primary stream 1 – Secondary stream 2 – Mobile stream</p> <p>SPLITDURATION=<value> Maximum number of seconds per file before split.</p> <p>THUMBNAIL=<value> Enable or Disable record thumbnail, valid value is: 0 – Disable 1 – Enable</p> <p>FILENAME=<value> Define file name of recording file, valid value is: 0~64 characters</p> <p>SUFFIX=<value> Select suffix of image file name, valid value is: 1 – Select time as suffix of file name 2 – Select time and recording time as suffix of file name</p>
Description	Set Storage Continuous Recording Parameters
Response	000 Success 100 Failed

Get Storage FTP Sending Parameters

Command Name	Get Storage FTP Sending Parameters
Command URL	http://<Camera IP>/form/getStorageFtpSending
Parameters	Null
Description	Get Storage files FTP sending Parameters
Response	<p>000 Success 100 Failed</p> <p>ENABLE=<value> Enable or Disable function, valid value is: 0 – Disable 1 – Enable</p> <p>SCHED=<value> Select schedule for Effective period or not, valid value is: 0 – Do not select schedule 1 – Select schedule</p> <p>SCHEDID=<value> Select schedule ID, valid value is: 1~4</p> <p>SERVER=<value> FTP Server name or IP address, Valid Value is: 0~64 characters</p> <p>PORT=<value> FTP Server port number, Valid Value is: 1~65535</p> <p>REMOTEPATH=<value> Remote path of server, valid value is: 0~64 characters</p> <p>AUTH=<value> FTP server needs authentication or not, Valid Value is: 0 – no authentication 1 – needs authentication</p> <p>USERNAME=<value> Login user name, Valid Value is: 0~64 characters</p> <p>PASSWORD=<value> Login password, Valid Value is: 0~128 characters</p>

Set Storage FTP Sending Parameters

Command Name	Set Storage FTP Sending Parameters
Command URL	http://<Camera IP> /form/setStorageFtpSending?<Param1>&<Param2>& ...
Parameters	<p>ENABLE=<value> Enable or Disable function, valid value is: 0 – Disable 1 – Enable</p> <p>SCHED=<value> Select schedule for Effective period or not, valid value is: 0 – Do not select schedule 1 – Select schedule</p> <p>SCHEDID=<value> Select schedule ID, valid value is: 1~4</p> <p>SERVER=<value> FTP Server name or IP address, Valid Value is: 0~64 characters</p> <p>PORT=<value> FTP Server port number, Valid Value is: 1~65535</p> <p>AUTH=<value> FTP server needs authentication or not, Valid Value is: 0 – no authentication 1 – needs authentication</p> <p>USERNAME=<value> Login user name, Valid Value is: 0~64 characters</p> <p>PASSWORD=<value> Login password, Valid Value is: 0~128 characters</p> <p>REMOTEPATH=<value> Remote path of server, valid value is: 0~64 characters</p>
Description	Get Storage files FTP sending Parameters
Response	000 Success 100 Failed

Get Identity Parameters

Command Name	Get Identity Parameters
Command URL	http://<Camera IP>/form/getIdentity
Parameters	Null
Description	Get identity parameters
Response	000 Success 100 Failed NAME=<value> System name, valid value is: 0~30 characters CONTACT=<value> System contact, valid value is: 0~50 characters LOCATION=<value> System location, valid value is: 0~50 characters

Set Identity Parameters

Command Name	Set Identity Parameters
Command URL	http://<Camera IP>/form/setIdentity?<Param1>&<Param2>& ...
Parameters	NAME=<value> System name, valid value is: 0~30 characters CONTACT=<value> System contact, valid value is: 0~50 characters LOCATION=<value> System location, valid value is: 0~50 characters
Description	Set Identity parameters
Response	000 Success 100 Failed

Add User

Command Name	Add User
Command URL	http://<Camera IP>/form/addUser?<Param1>&<Param2>& ...
Parameters	USERNAME=<value> User name, valid value is: 0~32 characters PASSWORD=<value> Password, valid value is: 0~32 characters
Description	Add user
Response	000 Success 100 Failed

Edit User

Command Name	Edit User
Command URL	http://<Camera IP>/form/editUser?<Param1>&<Param2>& ...
Parameters	USERNAME=<value> User name needs to be previously defined, valid value is: 0~32 characters PASSWORD=<value> Password, valid value is: 0~32 characters
Description	Edit user
Response	000 Success 100 Failed

Delete User

Command Name	Delete User
Command URL	http://<Camera IP>/form/deleteUser?<Param1>&<Param2>& ...
Parameters	USERNAME=<value> User name needs to be previously defined, valid value is: 0~32 characters
Description	Delete user
Response	000 Success 100 Failed

Get User List

Command Name	Get User List
Command URL	http://<Camera IP>/form/getUserList
Parameters	Null
Description	Get user list
Response	<p>000 Success</p> <p>100 Failed</p> <p>NUM=<value> Number of users, valid value is: 0~63</p> <p>USERNAME0=<value> Name of user0, valid value is: 0~32 characters</p> <p>PASSWORD0=<value> Password of user0, valid value is: 0~32 characters</p> <p>USERNAME1=<value> Name of user0, valid value is: 0~32 characters</p> <p>PASSWORD1=<value> Password of user0, valid value is: 0~32 characters</p> <p>...</p> <p>...</p> <p>...</p>

Get Active Users List

Command Name	Get Active Users List
Command URL	http://<Camera IP>/form/getActiveUserList
Parameters	Null
Description	Get active users list
Response	<p>000 Success</p> <p>100 Failed</p> <p>NUM=<value> Number of users, valid value is: 0~16</p> <p>USERNAME0=<value> Name of user0, valid value is: 0~32 characters</p> <p>IP0=<value> IP address of user0, valid value is: IP address data</p> <p>USERNAME1=<value> Name of user1, valid value is: 0~32 characters</p> <p>IP1=<value> IP address of user1, valid value is: IP address data</p> <p>...</p> <p>...</p> <p>...</p>

Get Allow Anonymous Access Parameters

Command Name	Get Allow Anonymous Access Parameters
Command URL	http://<Camera IP>/form/getAnonymousAccess
Parameters	Null
Description	Get allow anonymous access parameters
Response	000 Success 100 Failed ENABLE=<value> Allow or don't allow anonymous access to camera, valid value is: 0 – Don't allow 1 – Allow

Set Allow Anonymous Access Parameters

Command Name	Set Allow Anonymous Access Parameters
Command URL	http://<Camera IP>/form/setAnonymousAccess?<Param1>&<Param2>& ...
Parameters	ENABLE=<value> Allow or don't allow anonymous access to camera, valid value is: 0 – Don't allow 1 – Allow
Description	Set allow anonymous access parameters
Response	000 Success 100 Failed

Get Authentication Method

Command Name	Get Authentication Method
Command URL	http://<Camera IP>/form/getAuthMethod
Parameters	Null
Description	Get HTTP/RTSP authentication method
Response	000 Success 100 Failed AUTHMETHOD=<value> valid value is: 1 - Basic Authentication 2 - Digest Access Authentication

Set Authentication Method

Command Name	Set Authentication Method
Command URL	http://<Camera IP>/form/setAuthMethod?<Param1>&<Param2>& ...
Parameters	AUTHMETHOD=<value> valid value is: 1 - Basic Authentication 2 - Digest Access Authentication
Description	Set HTTP/RTSP authentication method
Response	000 Success 100 Failed

Get Date and Time

Command Name	Get Date and Time
Command URL	http://<Camera IP>/form/getDateTime
Parameters	Null
Description	Get date and time
Response	<p>000 Success 100 Failed</p> <p>TIMEZONE=<value> Timezone, valid value is:</p> <ul style="list-style-type: none"> 0 (UTC-12:00) International Date Line West 110 (UTC-11:00) Coordinated Universal Time -11 200 (UTC-10:00) Hawaii 300 (UTC-09:00) Alaska 400 (UTC-08:00) Pacific Time (US and Canada) 410 (UTC-08:00) Baja California 510 (UTC-07:00) Chihuahua, La Paz, Mazatlan 500 (UTC-07:00) Mountain Time (US and Canada) 520 (UTC-07:00) Arizona 630 (UTC-06:00) Guadalajara, Mexico City, Monterrey 600 (UTC-06:00) Saskatchewan 620 (UTC-06:00) Central Time (US and Canada) 610 (UTC-06:00) Central America 710 (UTC-05:00) Bogota, Lima, Quito 700 (UTC-05:00) Eastern Time (US and Canada) 720 (UTC-05:00) Indiana (East) 840 (UTC-04:30) Caracas 800 (UTC-04:00) Atlantic Time (Canada) 810 (UTC-04:00) Cuiaba 830 (UTC-04:00) Georgetown, La Paz, Manaus, San Juan 820 (UTC-04:00) Santiago 850 (UTC-04:00) Asuncion 900 (UTC-03:30) Newfoundland 910 (UTC-03:00) Brasilia 950 (UTC-03:00) Buenos Aires 920 (UTC-03:00) Greenland 940 (UTC-03:00) Cayenne, Fortaleza 930 (UTC-03:00) Montevideo 960 (UTC-03:00) Salvador 1010 (UTC-02:00) Coordinated Universal Time -02

1000 (UTC-02:00) Mid-Atlantic
1110 (UTC-01:00) Cape Verde Is.
1100 (UTC-01:00) Azores
1200 (UTC) Dublin, Edinburgh, Lisbon, London
1220 (UTC) Casablanca
1210 (UTC) Monrovia, Reykjavik
1230 (UTC) Coordinated Universal Time
1360 (UTC+01:00) Tripoli
1340 (UTC+01:00) Amsterdam, Berlin, Bern, Rome, Stockholm,
Vienna
1300 (UTC+01:00) Belgrade, Bratislava, Budapest, Ljubljana,
Prague
1320 (UTC+01:00) Brussels, Copenhagen, Madrid, Paris
1310 (UTC+01:00) Sarajevo, Skopje, Warsaw, Zagreb
1350 (UTC+01:00) Windhoek
1330 (UTC+01:00) West Central Africa
1460 (UTC+02:00) Beirut
1480 (UTC+02:00) Damascus
1400 (UTC+02:00) Minsk
1470 (UTC+02:00) Harare, Pretoria
1420 (UTC+02:00) Helsinki, Kyiv, Riga, Sofia, Tallinn, Vilnius
1410 (UTC+02:00) Cairo
1430 (UTC+02:00) Athens, Bucharest
1440 (UTC+02:00) Jerusalem
1490 (UTC+02:00) Istanbul
1450 (UTC+02:00) Amman
1510 (UTC+03:00) Baghdad
1530 (UTC+03:00) Kaliningrad
1500 (UTC+03:00) Kuwait, Riyadh
1520 (UTC+03:00) Nairobi
1550 (UTC+03:30) Tehran
1600 (UTC+04:00) Abu Dhabi, Muscat
1620 (UTC+04:00) Yerevan
1610 (UTC+04:00) Baku
1650 (UTC+04:00) Port Louis
1640 (UTC+04:00) Tbilisi
1540 (UTC+04:00) Moscow, St. Petersburg, Volgograd
1630 (UTC+04:30) Kabul
1710 (UTC+05:00) Tashkent
1750 (UTC+05:00) Islamabad, Karachi
1720 (UTC+05:30) Chennai, Kolkata, Mumbai, New Delhi
1730 (UTC+05:30) Sri Jayawardenepura
1740 (UTC+05:45) Kathmandu
1800 (UTC+06:00) Astana
1830 (UTC+06:00) Dhaka

	<p>1700 (UTC+06:00) Ekaterinburg 1820 (UTC+06:30) Yangon (Rangoon) 1910 (UTC+07:00) Bangkok, Hanoi, Jakarta 1810 (UTC+07:00) Novosibirsk 2000 (UTC+08:00) Beijing, Chongqing, Hong Kong, Urumqi 2020 (UTC+08:00) Kuala Lumpur, Singapore 1900 (UTC+08:00) Krasnoyarsk 2040 (UTC+08:00) Perth 2030 (UTC+08:00) Taipei 2050 (UTC+08:00) Ulaanbaatar 2110 (UTC+09:00) Osaka, Sapporo, Tokyo 2100 (UTC+09:00) Seoul 2010 (UTC+09:00) Irkutsk 2140 (UTC+09:30) Adelaide 2130 (UTC+09:30) Darwin 2210 (UTC+10:00) Brisbane 2240 (UTC+10:00) Guam, Port Moresby 2220 (UTC+10:00) Hobart 2200 (UTC+10:00) Canberra, Melbourne, Sydney 2120 (UTC+10:00) Yakutsk 2230 (UTC+11:00) Vladivostok 2300 (UTC+11:00) Solomon Is., New Caledonia 2410 (UTC+12:00) Auckland, Wellington 2400 (UTC+12:00) Fiji 2310 (UTC+12:00) Magadan 2430 (UTC+12:00) Coordinated Universal Time +12 2500 (UTC+13:00) Nuku'alofa 2510 (UTC+13:00) Samoa</p> <p>DAYLIGHT=<value> Enable or disable daylight saving time, valid value is: 0 – Disable 1 – Enable</p> <p>SECOND=<value> Greenwich time, valid value is: 0 ~ 2147450000 (Second)</p>
--	--

Set Date and Time

Command Name	Set Date and Time
Command URL	http://<Camera IP>/form/setDateTime?<Param1>&<Param2>& ...
Parameters	<p>TIMEZONE=<value></p> <p>Timezone, valid value is:</p> <ul style="list-style-type: none"> 0 (UTC-12:00) International Date Line West 110 (UTC-11:00) Coordinated Universal Time -11 200 (UTC-10:00) Hawaii 300 (UTC-09:00) Alaska 400 (UTC-08:00) Pacific Time (US and Canada) 410 (UTC-08:00) Baja California 510 (UTC-07:00) Chihuahua, La Paz, Mazatlan 500 (UTC-07:00) Mountain Time (US and Canada) 520 (UTC-07:00) Arizona 630 (UTC-06:00) Guadalajara, Mexico City, Monterrey 600 (UTC-06:00) Saskatchewan 620 (UTC-06:00) Central Time (US and Canada) 610 (UTC-06:00) Central America 710 (UTC-05:00) Bogota, Lima, Quito 700 (UTC-05:00) Eastern Time (US and Canada) 720 (UTC-05:00) Indiana (East) 840 (UTC-04:30) Caracas 800 (UTC-04:00) Atlantic Time (Canada) 810 (UTC-04:00) Cuiaba 830 (UTC-04:00) Georgetown, La Paz, Manaus, San Juan 820 (UTC-04:00) Santiago 850 (UTC-04:00) Asuncion 900 (UTC-03:30) Newfoundland 910 (UTC-03:00) Brasilia 950 (UTC-03:00) Buenos Aires 920 (UTC-03:00) Greenland 940 (UTC-03:00) Cayenne, Fortaleza 930 (UTC-03:00) Montevideo 960 (UTC-03:00) Salvador 1010 (UTC-02:00) Coordinated Universal Time -02 1000 (UTC-02:00) Mid-Atlantic 1110 (UTC-01:00) Cape Verde Is. 1100 (UTC-01:00) Azores 1200 (UTC) Dublin, Edinburgh, Lisbon, London 1220 (UTC) Casablanca

1210 (UTC) Monrovia, Reykjavik
1230 (UTC) Coordinated Universal Time
1360 (UTC+01:00) Tripoli
1340 (UTC+01:00) Amsterdam, Berlin, Bern, Rome, Stockholm, Vienna
1300 (UTC+01:00) Belgrade, Bratislava, Budapest, Ljubljana, Prague
1320 (UTC+01:00) Brussels, Copenhagen, Madrid, Paris
1310 (UTC+01:00) Sarajevo, Skopje, Warsaw, Zagreb
1350 (UTC+01:00) Windhoek
1330 (UTC+01:00) West Central Africa
1460 (UTC+02:00) Beirut
1480 (UTC+02:00) Damascus
1400 (UTC+02:00) Minsk
1470 (UTC+02:00) Harare, Pretoria
1420 (UTC+02:00) Helsinki, Kyiv, Riga, Sofia, Tallinn, Vilnius
1410 (UTC+02:00) Cairo
1430 (UTC+02:00) Athens, Bucharest
1440 (UTC+02:00) Jerusalem
1490 (UTC+02:00) Istanbul
1450 (UTC+02:00) Amman
1510 (UTC+03:00) Baghdad
1530 (UTC+03:00) Kaliningrad
1500 (UTC+03:00) Kuwait, Riyadh
1520 (UTC+03:00) Nairobi
1550 (UTC+03:30) Tehran
1600 (UTC+04:00) Abu Dhabi, Muscat
1620 (UTC+04:00) Yerevan
1610 (UTC+04:00) Baku
1650 (UTC+04:00) Port Louis
1640 (UTC+04:00) Tbilisi
1540 (UTC+04:00) Moscow, St. Petersburg, Volgograd
1630 (UTC+04:30) Kabul
1710 (UTC+05:00) Tashkent
1750 (UTC+05:00) Islamabad, Karachi
1720 (UTC+05:30) Chennai, Kolkata, Mumbai, New Delhi
1730 (UTC+05:30) Sri Jayawardenepura
1740 (UTC+05:45) Kathmandu
1800 (UTC+06:00) Astana
1830 (UTC+06:00) Dhaka
1700 (UTC+06:00) Ekaterinburg
1820 (UTC+06:30) Yangon (Rangoon)
1910 (UTC+07:00) Bangkok, Hanoi, Jakarta
1810 (UTC+07:00) Novosibirsk
2000 (UTC+08:00) Beijing, Chongqing, Hong Kong, Urumqi

	2020 (UTC+08:00) Kuala Lumpur, Singapore 1900 (UTC+08:00) Krasnoyarsk 2040 (UTC+08:00) Perth 2030 (UTC+08:00) Taipei 2050 (UTC+08:00) Ulaanbaatar 2110 (UTC+09:00) Osaka, Sapporo, Tokyo 2100 (UTC+09:00) Seoul 2010 (UTC+09:00) Irkutsk 2140 (UTC+09:30) Adelaide 2130 (UTC+09:30) Darwin 2210 (UTC+10:00) Brisbane 2240 (UTC+10:00) Guam, Port Moresby 2220 (UTC+10:00) Hobart 2200 (UTC+10:00) Canberra, Melbourne, Sydney 2120 (UTC+10:00) Yakutsk 2230 (UTC+11:00) Vladivostok 2300 (UTC+11:00) Solomon Is., New Caledonia 2410 (UTC+12:00) Auckland, Wellington 2400 (UTC+12:00) Fiji 2310 (UTC+12:00) Magadan 2430 (UTC+12:00) Coordinated Universal Time +12 2500 (UTC+13:00) Nuku'alofa 2510 (UTC+13:00) Samoa DAYLIGHT=<value> Enable or disable daylight saving time, valid value is: 0 – Disable 1 – Enable SECOND=<value> Greenwich time, valid value is: 0 ~ 2147450000 (Second)
Description	Set date and time
Response	000 Success 100 Failed

Get Date Format

Command Name	Get Date Format
Command URL	http://<Camera IP>/form/getDateFormat
Parameters	Null
Description	Get date format
Response	000 Success 100 Failed FORMAT=<value> Select date and time format, valid value is: 0 – yy/mm/dd hh:mm:ss 1 – mm/dd/yy hh:mm:ss 2 – dd/mm/yy hh:mm:ss

Set Date Format

Command Name	Set Date Format
Command URL	http://<Camera IP>/form/setDateFormat?<Param1>&<Param2>& ...
Parameters	FORMAT=<value> Select date and time format, valid value is: 0 – yy/mm/dd hh:mm:ss 1 – mm/dd/yy hh:mm:ss 2 – dd/mm/yy hh:mm:ss
Description	Set date format
Response	000 Success 100 Failed

Get NTP Parameters

Command Name	Get NTP Parameters
Command URL	http://<Camera IP>/form/getNtp
Parameters	Null
Description	Get NTP parameters
Response	ENABLE=<value> Enable or disable NTP function, valid value is: 0 – Disable NTP 1 – Enable NTP SERVER=<value> NTP server name or IP address, valid value is: 0-63 characters

Set NTP Parameters

Command Name	Set NTP Parameters
Command URL	http://<Camera IP>/form/setNtp?<Param1>&<Param2>& ...
Parameters	ENABLE=<value> Enable or disable NTP function, valid value is: 0 – Disable NTP 1 – Enable NTP SERVER=<value> NTP server name or IP address, valid value is: 0-63 characters
Description	Set NTP parameters
Response	000 Success 100 Failed

Get Auto Reboot Parameters

Command Name	Get Auto Reboot Parameters
Command URL	http://<Camera IP>/form/getAutoReboot
Parameters	Null
Description	Get auto reboot parameters
Response	<p>ENABLE=<value> Enable or disable Auto Reboot function, valid value is: 0 – Disable Auto Reboot 1 – Enable Auto Reboot</p> <p>DAY=<value> Reboot day, valid value is: 0 - Sunday 1 - Monday 2 - Tuesday 3 - Wednesday 4 - Thursday 5 - Friday 6 - Saturday 7 - Every day</p> <p>TIME=<value> Reboot time, valid value is 0-23.</p>

Set Auto Reboot Parameters

Command Name	Set Auto Reboot Parameters
Command URL	http://<Camera IP>/form/setAutoReboot?<Param1>&<Param2>& ...
Parameters	<p>ENABLE=<value> Enable or disable Auto Reboot function, valid value is: 0 – Disable Auto Reboot 1 – Enable Auto Reboot</p> <p>DAY=<value> Reboot day, valid value is: 0 - Sunday 1 - Monday 2 - Tuesday 3 - Wednesday 4 - Thursday 5 - Friday 6 - Saturday 7 - Every day</p> <p>TIME=<value> Reboot time, valid value is 0-23.</p>
Description	Set auto reboot parameters
Response	<p>000 Success</p> <p>100 Failed</p>

System Reboot

Command Name	System Reboot
Command URL	http://<Camera IP>/form/sysReboot
Parameters	Null
Description	System reboot
Response	000 Success 100 Failed

Get Model

Command Name	Get Model
Command URL	http://<Camera IP>/form/getModel
Parameters	Null
Description	Get model
Response	000 Success 100 Failed VENDOR=Sharx MODEL=<value> Camera model

Get Firmware Version

Command Name	Get Firmware Version
Command URL	http://<Camera IP>/form/getFirmwareVersion
Parameters	Null
Description	Get firmware version
Response	000 Success 100 Failed MAJOR=<value> Firmware major, valid value is: 0~99 MINOR=<value> Firmware minor, valid value is: 0~99 BUILD=<value> Firmware build number, valid value is: 0~8 characters

Get Hardware Address

Command Name	Get Hardware Address
Command URL	http://<Camera IP>/form/getHardwareAddress
Parameters	Null
Description	Get hardware address
Response	000 Success 100 Failed HWADDR=<value> Camera hardware address

Get System Information

Command Name	Get System Information
Command URL	http://<Camera IP>/form/getSystemInformation
Parameters	Null
Description	Get system information
Response	<p>000 Success 100 Failed</p> <p>VENDOR=Sharx</p> <p>MODEL=<value> Camera model</p> <p>HWADDR=<value> Network hardware address</p> <p>LOADERVERSION=<value> The loader version</p> <p>FIRMWAREVERSION=<value> The firmware version</p> <p>ACTIVEXVERSION=<value> The ActiveX control version</p> <p>UPTIME=<value> System up time</p>

Appendix URL Command Testing

Video

<http://<IP address>/form/getVideo>

<http://<IP address>/form/setVideo?LIGHTFREQ=50&HFLIP=0&VFLIP=0>

Audio

<http://<IP address>/form/getAudio>

<http://<IP address>/form/setAudio?ENABLE=0&VOLUME=1>

Speaker

<http://<IP address>/form/getSpeaker>

<http://<IP address>/form/setSpeaker?ENABLE=0&VOLUME=8>

Privacy mode

<http://<IP address>/form/getPrivacy>

<http://<IP address>/form/setPrivacy?ENABLE=0>

Stream

<http://<IP address>/form/getStream?TYPE=1>

<http://<IP address>/form/setStream?TYPE=1&ENABLE=1&SIZE=FSIZE&FRAMERATE=30&H264BITRATE=2048&MPEG4BITRATE=2048&MJPEGQUALITY=50&JPEGQUALITY=90&AUDIOCODEC=AACLC&AUDIOBITRATE=24000&AUTH=1>